


BASIC OPERATION

After powering up your video monitor, the parent unit streams live video in direct mode. You can also adjust the video monitor's settings for functionality, enhancements, and mobile access. See **Auto software and firmware update** and **Download app for mobile access** in this quick start guide.

Use the menu:
Press **MENU** on the parent unit to enter the main menu, choose a menu item, or save a setting. You can use the parent unit as a remote control to adjust the volume of the video monitor, stop the video monitor, or adjust the motion and sound detection settings.

- Press **A**, **V**, or **>** to scroll among the menu options.
- Press **SELECT** to select an item.
- Press **BACK** to return to the live video.
- Press **Q** to go to the **Help & Info** page.

Zoom:
Press **Q** to zoom in or out.



Adjust speaker volume:
Press **MENU** on the parent unit to adjust the speaker volume. It determines the volume of sound transmitted from your baby unit.



Talk to your baby via the baby unit

- Press and hold the **TALK** key.
- When the **TALK** icon displays on the screen, speak to your parent unit, and your baby unit will transmit to the baby unit.
- When finished talking, release the **TALK** key and hear your baby again.

Turn on/off baby unit status LED

You may see the status LED indicator of your baby unit on or off. Go to:

- Status LED**

Turn on/off the parent unit screen

You can turn on or off the parent unit screen. Press **MENU** on the parent unit. You can still be connected to the baby unit when the screen is off.

- Press **POWER** on the parent unit to turn off the screen.
- Press any key on the parent unit to turn on the screen again.

Tip: You can reset the parent unit by pressing the **RESET** key at the back of the unit.

Use a pin and insert it into the hole on the parent unit, and then press the button below.

TEST THE LOCATION FOR THE BABY UNIT

If you plan to install your baby unit in a designated location, and use your home Wi-Fi network to connect your video monitor, you need to test the location for the baby unit. You should test the location for 24 hours with good Wi-Fi signal strength. After you have powered on your parent unit, you can use the parent unit to test the location for the baby unit. To assist in checking, once you have identified the suitable location, you can install your baby unit. You can also use the parent unit to test the Wi-Fi router frequency.

- Tip:** Depending on your location and the Wi-Fi network, you may experience signal strength fluctuations. To improve the Wi-Fi signal strength, you can adjust the location of the parent unit. Check with your parent unit again.

NEED HELP?

Driven by system updates, the software, online help topics, and online FAQs will be updated periodically.

- For operations and guides to help you using your HD video monitor, and for latest online FAQs, go and check the online help. Use your smartphone or mobile device to access our online help.
- Go to <https://help.vtechphones.com/ms754hd> or <https://help.vtechphones.com/ms754-2hd>. OR
- Scan the QR code on the right. Launch the camera app or QR code scanner app on your smartphone or tablet. Hold the notification to open the connection of the online help.

If the QR code is not clearly displayed, adjust your camera's focus by moving your device closer or further away until it is clear.

If you would like to contact us, visit <https://help.vtechphones.com/c4>, 1-844-848-8300 or 1-844-848-8300 (in Canada) for help.

RM754-2HD online help


RM754-2HD online help

TEST THE SOUND LEVEL AND POSITION THE HD VIDEO MONITOR

Note: This feature is intended for an adult to check a substitute for proper adult supervision, and should not be used as such.

Testing the sound level of the HD video monitor:
For hearing protection, make sure the parent unit is more than 3 meters away from the baby unit when testing the sound level. You can also press **VOL** on the parent unit to lower or raise the tone.

- Tip:** Increase the parent unit speaker volume if you cannot hear the sounds transmitted from the baby unit.



Positioning the HD video monitor

Keep the baby unit out of the reach of your baby. Never place or mount the baby unit inside the baby's crib or other sleeping area.

- Place the baby unit more than 1 meter away from your baby.
- Adjust the angle of the baby unit to aim at your baby.

DOWNLOAD APP FOR MOBILE ACCESS

- You can download the **MyVtech Baby 1080p** mobile app and install it to a mobile device, then use your mobile device and the mobile app to monitor your areas remotely.
- Press **MENU** when the parent unit is idle.
- Go to **Connect Mobile Phone**.
- Scan the QR code in the parent unit to download the app into your mobile device.
- Follow the instructions in the mobile app to set up and pair your baby unit to the mobile app.

Alternatively, you can download the mobile app from the App Store or Google Play store.

Install MyVtech Baby 1080p mobile app

- Browse the App Store or Google Play store.
- Search for the mobile app with the keyword "myvtech baby 1080p".
- Download and install the **MyVtech Baby 1080p** mobile app to your mobile device.

OK

Note: Make sure your mobile device meets the minimum requirement for the mobile app.


The minimum requirement for the mobile app is:

- Compatible with:
- iOS 8.0 or later;
- Android 4.0 or later;

After installing the mobile app, follow the instructions in the mobile app and parent unit to set up and pair your baby unit.

In your mobile device:

- Tap **+** to scan the mobile app in your mobile device, and then create a camera account.
- We recommend that you use common network services (e.g., Google Cloud for Photos, Facebook, Twitter, etc.) to create a camera account. You can also create your new camera account via the email link, then sign in to your account.
- Follow the instructions in the mobile app to pair the camera. Tap **+** in the mobile app to get the QR code.



AUTO SOFTWARE AND FIRMWARE UPDATE

To ensure that your HD video monitor is always at its best performance, the parent unit will automatically update its software and the baby unit's firmware when there are new versions available.

Follow the instructions on the parent unit screen to update your HD video monitor. If you skip the updates, the parent unit and baby unit will be updated automatically when the parent unit is powered off, and then powered on again.

Connect your HD video monitor with home Wi-Fi network

- You must connect your video monitor to your secured home Wi-Fi network in order to receive the latest software and firmware updates. To set it up, go to **Configure Wi-Fi**.

MOUNT THE BABY UNIT (OPTIONAL)

- Place the wall mount bracket on a wall and then use a pencil to mark the hole locations. Use the provided wall mount bracket and drill two holes in the wall (7/32 inch drill bit).
- Check for electrical strength and drilling the holes. Use a pencil to mark the hole locations. Use the provided wall mount bracket and drill two holes in the wall (7/32 inch drill bit).
- Align the wall mount bracket and screw with the hole in the wall as shown. Tighten the screw in the middle hole first, so that the wall mount bracket is centered. Then you can tighten the other screws in the top hole.
- Place the baby unit on the wall mount bracket and then slide it forward until it locks into place. Connect the power adapter to the baby unit and a power supply not controlled by a wall switch.



- You can maximize your baby unit viewing angle by tilting the wall mount bracket. Tilt your baby unit up or down to adjust to your preferred angle. Then, rotate the knob in clockwise direction to tighten the joint and secure the angle.

GENERAL PRODUCT CARE

- To keep this product working well and looking good, follow these guidelines:
- Avoid putting in room heating appliances and devices that generate electrical noise (for example, DO NOT expose it to direct sunlight or moisture).
- Avoid dropping the product or treating it roughly.
- Do not touch the screen with your fingers or sharp objects.
- DO NOT use cleaning spray or liquid cleaners.
- Make sure the parent unit and the baby unit are dry before you connect them to the mains again.
- Clean the USB charging port of dust, dirt, and irregularity.

STORAGE

When you are not going to use the HD video monitor for some time, store the parent unit, the baby unit and the adapters in a cool and dry place.

FREQUENTLY ASKED QUESTIONS

Below are the questions most frequently asked about the HD video monitor. Can't turn off the screen? Press **MENU/SELECT** will turn the LCD display back on from the baby unit.

Why does the baby unit not respond normally? 1. Disconnect the power to the baby unit. 2. Reconnect the power to the baby unit. 3. Restart the parent unit.

Why turn on when in black and white? The baby unit has a light sensor that measures the ambient light. When the ambient light is dim, such as during nighttime or in a dark room, the baby unit activates its infrared LEDs, and displays the camera view in black and white. Why does my baby unit not connect to the Internet? Check your network and the connection status. Make sure the baby unit is connected to the Internet.

Why don't I hear a volume? The parent unit speaker volume may be too low. Press **VOL+** to increase the volume. Why isn't my baby unit responding? Please check the volume of the parent unit and the baby unit. Higher level for details, go to www.vtechphones.com for online help topics.

LIMITED WARRANTY

What does the limited warranty cover? The manufacturer of this product warrants to the holder of a valid proof of purchase ("Consumer") that, upon the return of the product to the manufacturer or its authorized service center, it will provide a replacement product or repair at its discretion. This limited warranty does not cover the product if the product is damaged by accident, misuse, or if the product is used for a purpose not intended by the manufacturer. This limited warranty is void if the product is damaged by accident, misuse, or if the product is used for a purpose not intended by the manufacturer.

What is not covered by the limited warranty? 1. Products that have been subjected to misuse, accident, dropping or other physical damage, improper installation, abnormal use, or other factors that are not the responsibility of the manufacturer. 2. Products that have been damaged due to repair, alteration or modification by anyone other than an authorized service center. 3. Products that have been damaged due to natural conditions, network availability, or cable or antenna damage. 4. Products that are damaged by fire, flood, lightning, or other natural disasters. 5. Products that are damaged by liquid, oil, or other substances that are not intended to be used on the product. 6. Products that are damaged by use of unauthorized accessories or components, or by use of unauthorized repair services. 7. Products that are damaged by use of unauthorized repair services. 8. Products that are damaged by use of unauthorized repair services.

How long is the limited warranty period? The limited warranty period for the mobile app is for ONE (1) YEAR from the date of purchase. If you observe or experience any defect in the product within the limited warranty period, you must file a claim with the manufacturer within the limited warranty period. The limited warranty period for the baby unit is for ONE (1) YEAR from the date of purchase. If you observe or experience any defect in the product within the limited warranty period, you must file a claim with the manufacturer within the limited warranty period.

Where can I get more information? For more information, please contact our customer service team at 1-844-848-8300. You can also visit our website at <https://help.vtechphones.com>. You can also visit our website at <https://help.vtechphones.com>. You can also visit our website at <https://help.vtechphones.com>.

What does the manufacturer's warranty cover? The manufacturer's warranty covers the product for a period of ONE (1) YEAR from the date of purchase. If you observe or experience any defect in the product within the limited warranty period, you must file a claim with the manufacturer within the limited warranty period. The limited warranty period for the baby unit is for ONE (1) YEAR from the date of purchase. If you observe or experience any defect in the product within the limited warranty period, you must file a claim with the manufacturer within the limited warranty period.

Other limitations: The manufacturer's warranty does not cover the product if the product is damaged by accident, misuse, or if the product is used for a purpose not intended by the manufacturer. This limited warranty is void if the product is damaged by accident, misuse, or if the product is used for a purpose not intended by the manufacturer.

Please retain your original sales receipt as proof of purchase. The manufacturer's warranty is void if the product is damaged by accident, misuse, or if the product is used for a purpose not intended by the manufacturer. This limited warranty is void if the product is damaged by accident, misuse, or if the product is used for a purpose not intended by the manufacturer.