## Operation Description

1. The USB power plug of speaker is plugged in.



- Turn on the power and enter the LINE \_\_\_\_ function by default. The red LED is always on. At this time, the audio cable can be inserted into the audio device to play music.
- 3. Short press \* button on the remote control to enter the Bluetooth status, and the blue LEDs will flash alternately. At this time, you can pair the Bluetooth device. After the pairing is successful, there will make a notification sound. The blue LED is always on. At this time, the audio device can play music.
- 4. Short press button on the remote control to stop playing music, click again to resume playback. Short press which on the remote control, increase the volume, press twice consecutively to go to the previous song, long press which button on the remote control to increase the volume, and the speaker sounds louder. Short press on the remote control, the volume decreases, press twice consecutively to go to the next track, long press who button on the remote control to decrease the volume, and the speaker sound is reduced.
- 5. Pairing: In the Bluetooth status, long press button on the remote control for 3 seconds. When the speaker will make a notification sound, it indicates that the current pairing device is released and the pairing mode is entered. The blue LED flash alternately. At this time, Bluetooth device pairing can be performed.
- After press button on the remote control to enter the Bluetooth mode. If there
  is a paired device, it will return to the paired device. If there is no paired device, it
  will enter the pairing mode.
- In pairing mode, search for Bluetooth pairing device 3 times, and it will automatically turn off if there is no signal for 5 minutes in Bluetooth mode.
- 8. Turn off: Long press the button for 3 seconds to turn off power and the LED.
- After restarting, the volume level will automatically return to the middle value, and the last volume level will not be remembered.

## **Button Function**



	Status	Function	Button Operation	Description
1	Turn off	Turn on	Short press the hill button	The red LED is on when the USB power cord of speaker is plugged in, and enters LINE mode
	Power on	Bluetooth	Short press *button	Blue LED flash alternately and enter pairing status. The blue LED is always on.
	Power on	Line	Short press * button	When the speaker will make a notification sound, it indicates that the current LINE mode is entered. The red LED always on.
	Power on	Turn off	Long press the button for 3 seconds	Turn off power and LED.
2	Bluetooth / Line	Increase Volume	Short press 144 button V+ Long press 144 button	Short press the 144 button to increase volume.  V+ Long press the 144 button to increase volume continuously.
3	Bluetooth / Line	Decrease Volume	Shot press Hotton Long press Hotton	Short press the N-1 button to decrease volume Long press the N-1 button to decrease volume continuously.
4	Bluetooth	Previous Track	Press twice 144 button	Press twice V+  consecutively to go to the  previous track

	Status	Function	Button Operation	Description
5	Bluetooth	Next Track	Press twice >>1 button	Press twice H button consecutively to go to the next track
6	Play music	Pause	Short press *II button	Short press *II button to stop playing music, click again to resume playback.
	Line	Mute	Short press *II button	Short press the I button enters to mute status. Press it again, the music unmute.
7	Bluetooth	PAIR	Long press the button for 3 seconds	Long press the button for 3 seconds. When the speaker will make a notification sound, it indicates that the current pairing device is released and the pairing mode is entered. The blue LED flash alternately. At this time, Bluetooth device pairing can be performed.
8	•	RGB lighting touch control	Switch between ten lighting modes	Touch RGB lighting button can switch between ten lighting mode.

## FCC warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -ncrease the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.