

折叠方式: 风琴拉页


折叠成品尺寸 120*120MM

正面

Low power indicator


The mouse has low power indicator, when the power is nearly used up, the LED will flash to remind you to replace the battery.

After the power is completely used out, the LED will be off, so please replace the battery in time.



On/Off switch

On the bottom of the mouse, there is a On/Off switch. When you are traveling or on a plane or stop using it for a long time, please switch it to Off to save power. When reuse it, you need to switch it to On.



Battery Disposal

Don't throw away the batteries into the fire. After replace the batteries, put them to the right place for recycling.

Technical data

Frequency band: 2402MHz ~ 2479MHz

Power supply: 1.5V

Operation current: ≤7mA(1.5V)

Acceleration: up to 20G

Resolution: DPI 1000/1500/2000 switchable


The above technical data is for reference only, Fuhlen could update it without prior notification.



JF-T03 Wireless Sym.Nano Mouse User Guide

Package Contents:

- Wireless RF mouse
- USB nano receiver
- 2xAA batteries
- User guide



Thanks for buying Cherry products, please read this user guide carefully before use.

背面

Installation

- Switch the On/Off button to Off, and open the battery cover.
- Insert one or two AA battery as the diagram on the battery tray indicates. Close the battery cover.
- Switch the On/Off button to On, the LED indicator will flash one time.
- Plug the USB receiver into an available USB port on your computer. Press any key to start.

Set Wireless Connection

The JF-T03 mouse and USB receiver is pre-paired before packing. Users can use it after installing the battery.

- Turn on the computer.
- Plug the USB receiver into an available USB port on your computer.
- Install the battery into the mouse. Press any key to start.

Finished setting the wireless connection of the mouse, you can enjoy the wireless freedom.

Mouse Feature

Weight auto-adjustment

The mouse is with two parallel batteries as power supply, it can work normally no matter with one or two batteries. The weight of mouse can be adjusted according to the battery quantity.

DPI Switch

The mouse has 1000/1500/2000 of DPI for your choice freely. The factory default is 1000DPI. You can choose the DPI you like by pressing the DPI button of "+" or "-", the LED will flash different colours according to difference DPI.

DPI value	LED Colour
1000dpi	Red
1500dpi	Green
2000dpi	Orange

Side Buttons Feature

The mouse is with 2 side buttons. For Windows2000 or above, the buttons are defaulted as browser forward and backward buttons. For further function, please download the driver from the website of www.fuhlenstyle.com for your self-definition.

Energy-saving mode

The mouse is with energy saving mode, when you stop using it for 0.2s, it will automatically switch into the energy-saving mode, which can extend the battery life.

Receiver Build-in design

The mouse is with build-in design, when you stop using the nano USB receiver, it can be stowed away in a hidden compartment inside the mouse. It is more convenient for storing.

Federal Communications Commission (FCC) Notice:

All other devices shall bear the following statement in a conspicuous location or device: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS