

# LBS 10 Product Description



## Connect to LBS10

Slide Power button to ON

Searching the Bluetooth Speaker named LBS10 when the blue led is flashing.

connect LBS10 without password

## Hand Free

Press Hand Free to answer coming call

Press Hand Free again to hang it up

## AUX INPUT

It will change to AUX status automatically when you plug in 3.5mm audio cable.

## TF INPUT

It will change to TF status automatically when you plug in TF Card

## Charging


Charges LBS10 via Micro USB Cable, Red LED will be flashing when charging, and keep on after full charging.

## Technical Features

Drive Units	2x45mm
Amplifier power	3 w
Frequency response of AUDIO	150Hz - 20kHz
Signal-to-noise ratio	>80 dB
Battery type	Li-ion
Frequency range	2.402-2.480GHz

Working time	>5 hours @ 0.2W
Battery capacity	600mah
Battery charge time	2 hours
Dimensions (L x W x H)	155x47x42mm

### Operation Instruction



### FCC Warning Statement

FCC Statement This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation .

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is

connected.

-- Consult the dealer or an experienced radio/TV technician for help.