DRAFT COPY



JumpCharge User Manual

In the Box

- JumpCharge Desktop Unit
- AC Power Cable
- Ethernet Cable
- User Manual

Note: This unit is only permitted for use with the provided equipment.

Setup

Step 1: Go to https://jumpcharge.com/portal and register your unit using the Serial Number on the back of the unit. See the Web Portal Set-Up Instructions for further information.

Step 2: Plug the AC Power Cable and Ethernet into your JumpCharge unit. Ethernet connection is required for initial installation.

Step 3: Place your batteries into your JumpCharge unit.

You're all set! Anyone with the JumpCharge app can now tap their pass to checkout batteries from your JumpCharge unit.

DRAFT COPY

Regulatory Information

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device must not be collocated or operating in conjunction with any other antenna or transmitter.

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following 2 conditions:

- 1. These devices may not cause harmful interference.
- 2. These devices must accept any interference received, including interference that may cause undesired operation.

EMC compliance statement

Important: This device and its power adapter have demonstrated Electromagnetic Compatibility (EMC) compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, televisions, and other electronic devices.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF field in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Heath Canada's website www.hc-sc.gc.ca/rpb.