


# Emergency Pendant / Wrist Transmitter (Halo-VRI)

*Easy & Exchangeable Belt / Neck Cord styles*

*Long battery life*

*Waterproof*

Halo-VRI is designed to be worn by seniors as they move on the premises. In an emergency, help is merely a button press away.



## ● **Active Button**

- Pressing the Active Button for more than 1 second will activate the Control Panel, causing it to dial emergency call or alarm.
- Press and hold the Active Button for 8 seconds to send a Cancel Code to the Control Panel. (This function is not compatible with every control panel).
- Press and hold the button for 15 sec (until the LED flashes 3 times) to activate the **Auto Low Battery Detection**. Halo-VRI will automatically check battery voltage every 20-24 hours.

## ● **LED indicator**

- The LED will flash 6 times when the button is pressed.
- Flashes 3 times: When Auto Low Battery detection function is enabled.

## ● ***Learn in the Transmitter***

- Step 1. Put the Control Panel into the learning mode.
- Step 2. Press the Button on the Transmitter, a radio signal will be transmitted to the Control Panel.
- Step 3. Please refer to the operation manual of your Control Panel to complete the learning process.

## ● ***Battery Life***

The Transmitter uses one CR2032 3V Lithium battery as its power source.

Every time the Active Button is pressed, the Transmitter will check the battery voltage. If low battery is detected for 3 times successively, the Transmitter will enter low battery status and transmit Low Battery signal along with regular signal every time the button is pressed.

### <NOTE>

- ☞ A 30-second interval is required between each Active Button press to check the battery voltage again.

## ● ***Switching Between Lanyard/Wrist Band***

Step 1. Push the back of transmitter to take it off from the frame hooked with lanyard.



Step 2. Put the transmitter in the frame of the wrist band from the back side as shown in *Picture A*.

Step 3. Installation is completed as shown in *Picture B*.

**Picture A. The Back of the transmitter and the wrist band**



**Picture B. The front view of the transmitter with the wrist band**



## ● **Auto Low Battery Detection**

The Transmitter features Auto Low Battery detection function.

- Press and hold the Active Button for 15 seconds to activate this function (ignoring the 1<sup>st</sup> and 2<sup>nd</sup> set of LED flashes at the first and 8th seconds). The LED will flash 3 times to confirm.
- After activation, the Transmitter will automatically check battery voltage every 20-24 hours. If low battery is detected for 3 times successively, the Transmitter will enter low battery status and transmit low battery signal every 12 hours.

### <NOTE>

- ☞ If Auto Low Battery detection is not activated, the Transmitter will not automatically check battery status. You need to check battery status by manually pressing the Active Button.
- ☞ Once Auto Low Battery Detection is activated, it cannot be deactivated later in any circumstances.

## **Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- . Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- . Consult the dealer or an experienced radio/TV technician for help.

***FCC Caution:*** To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.