




POP SOLO™

PORTABLE WIRELESS KARAOKE MICROPHONE with Built-in Retractable Smartphone Holder

Model: 4955
FCC ID: HBO4955

USER MANUAL


HD Voice Ready




Includes:

- PopSolo Microphone with built-in smartphone holder
- Micro USB to USB Cable
- Micro USB to 3.5mm Audio Cable
- User Manual


Micro USB to 3.5mm Audio Cable




Micro USB to USB Cable



PopSolo Microphone



Works with most Karaoke apps



PAIRING TO BLUETOOTH DEVICE

Make sure the Bluetooth function is available on your electronic device. Specific pairing procedures may vary slightly depending on the device. For detailed information, please refer to your device's User Guide.


- After successful pairing, devices will remember each other. Therefore, no pairing will be needed next time.

1. Keep the distance between the device and the microphone within 3 feet (for pairing only).
2. Turn microphone on using power button.
4. Activate the Bluetooth function on your device to search for Bluetooth devices. Look for "Tzumi-PopSolo" in device list displayed and select.
5. Only for some electronic devices: Enter password, 0000.
6. Microphone is now ready for use.

BUILT-IN SMARTPHONE HOLDER

Built-in retractable phone holder is perfect for when you want to sing along while looking at the phone screen.

- STEP 1: Access the phone holder by pulling it UP.
STEP 2: Place the phone into the bracket. Fits smartphone up to 6 inches.



POP SOLO CONTROLS

- Turn ON/OFF _____ Press and hold
- Pause/Restart _____ Quickly press
- Accompaniment ON/OFF _____ Press and hold
- Turn microphone ON/OFF _____ Quickly press
- Increase volume _____ Press and hold
- Go to previous song _____ Quickly press
- Decrease volume _____ Press and hold
- Go to next song _____ Quickly press
- Adjust Echo effect _____ Push

IMPORTANT SAFEGUARDS

- Do not use this unit for anything other than its intended use.
- Keep the unit away from heat source, direct sunlight, humidity, water or any other liquid.
- Do not expose the device to extremely high or low temperatures, as it may damage the battery.
- Do not operate the unit if it has been wet or moist to prevent against electric shock and/or injury to yourself and damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Keep the unit out of reach of infants.

RECORDING WITH MICROPHONE

1. Keep the audio cable to your phone, plug the micro USB port into the bottom of the microphone base.
2. Open recording app, follow the instructions in the app and start recording.
3. When you are done recording, there are 2 ways to listen to your video:

LISTEN THROUGH THE MICROPHONE SPEAKERS:
Keep your phone plugged into the microphone and replay your video.


LISTEN THROUGH YOUR PHONE:
Unplug your phone from the microphone, turn the microphone off and replay your video.

Please note - iPhone® 7 & 7Plus does not have auxiliary jack. You will need your Apple supplied adapter to use this feature.

CHARGING THE MICROPHONE

1. When battery is low, the unit will automatically shut off.
2. Connect the Micro to USB cable from the microphone to a power source. The LED Indicator will light up red.
3. Charging will take about 2 hours. When the unit is done charging, the red light will shut off.

Note: You may use your microphone while it's charging.



FAQ / TROUBLESHOOTING

- Q: Why does pairing not work?**
A: The distance between your phone and the device may be too far. Bring the devices close together. The unit may already be paired with another phone in range. Unpair the unit from the other device.
- Q: Why does the microphone not turn on?**
A: Make sure the unit is fully charged before using it for the first time. The microphone will not turn on if battery level is very low.
- Q: There is sound distortion when playing music.**
A: Your phone signal may be weak, the volume may be too high or the battery power of the unit may be too low. Check the volume on both the device and your phone and make sure the microphone is fully charged.
- Q: Accompaniment sounds are weak or I hear static.**
A: The distance between your phone and the device may be too far. Close the distance between the phone and the unit. Also, check volume on your phone.
- Q: The sound is distorted when the music is playing.**
A: Make sure the unit is fully charged. Also, check the volume on both the device and your phone. Make sure the volume is not too high as this will affect the distortion of the music.
- Q: I can't play back my recording on my iPhone.**
A: Some apps may not support IOS and not record sound. Try using a different app or a device with a different operating system.

SPECIFICATIONS	Bluetooth Version _____	Bluetooth V4.1
	Standby Time _____	Up to 12 hours
	Charge Time _____	2 hours
	Power Source _____	Battery
	Continuous Play Time _____	4-5 hours
	Battery _____	Built-in Lithium: 5V 1300mAh
	Wireless Frequency _____	100-10KHz

tzumi PopSolo™ Karaoke Microphone Distributed by tzumi® Inc. NY, NY, 10016. ©Copyright 2016 tzumi Inc. All Rights Reserved. Made In China. SoloPop is a registered trademark of tzumi Inc. iPhone is a trademark of Apple Inc., registered in the U.S. and other countries. Samsung and Galaxy S are both registered trademarks of Samsung Electronics Co., Ltd. Google, the Google Logo, Android, Google Play, Google Play logo, Google Cardboard and YouTube are registered trademarks of Google Inc. All other trademarks or service marks are property of their respective owners. Subject to change without prior notice.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.