


TomTom Remote Control



EN

- A** Volume control
Adjust the volume up/down.
- B** Soft buttons
Left/center/right keys for use in the navigation screen. The center key is also used to play/pause tracks while listening to music.
- C** Arrow buttons
Horizontal: Select menu buttons and keyboard keys and go forward/rewind tracks while listening to music.
Vertical: Select menu buttons and keyboard keys and zoom in/out while viewing the navigation screen.
- D** OK button
Press a menu button or confirm an action.

ES

- A** Control de volumen
Suba/baje el volumen.
- B** Botones táctiles
Teclas izquierda/central/derecha para su uso en la pantalla de navegación. La tecla central también se utiliza para reproducir/detener en pausa pistas mientras se escucha música.
- C** Botones de flecha
Horizontal: Seleccione botones de menú y teclas de teclado y avance/retroceda en pistas mientras escucha música.
Vertical: Seleccione botones de menú y las teclas de teclado y aleje o acerque mientras visualiza la pantalla de navegación.
- D** Botón OK
Pulse un botón de menú o confirme una acción.

FR

- A** Réglage du volume
Permet d'augmenter/baisser le volume.
- B** Boutons de fonction
Touches gauche/centrale/droite à utiliser dans l'écran de navigation. La touche centrale sert également à lire/mettre en pause des titres lorsque vous écoutez de la musique.
- C** Boutons fléchés
Horizontaux : Pour sélectionner des boutons de menu et des touches de clavier, mais également avancer/reculer dans le titre que vous écoutez.
Verticaux : Pour sélectionner des boutons de menu et des touches de clavier, mais également effectuer un zoom avant/arrière dans l'écran de navigation.
- D** Bouton OK
Pour appuyer sur un bouton de menu ou confirmer une action.

FCC Regulations

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC Regulations

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation of the device.

FCC ID: HFS-ASTOM2

IC ID: 1787B-ASTOM2

Responsible party in North America

TomTom, Inc., 150 Baker Avenue Extension,
Concord, MA 01742

Tel: (866 486-6866) option 1 (1-866-4-TomTom)

Exposure to Radio Frequency Radiation

To comply with RF exposure requirements please maintain a separation distance of at least 20 cm / 7 inches from any part of the product.

Emissions information for Canada

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Part number: 6M01.004

TOMTOM™ 