

## CAUTION!

### RISK OF ELECTRICAL SHOCK. DO NOT REMOVE COVERS.

- Do not remove any covers.
- Refer servicing to qualified technicians only.
- Disconnect all power before servicing.
- Read and perform all instructions carefully. Failure to follow suggested instructions and guidelines may void all warranties.

### FCC STATEMENT

This equipment has been tested and found to comply with Part 74.637 (a) (2) of the FCC Rules and Regulations. Any unauthorized changes or modifications not expressly approved by Nucomm, Inc. could void the user's authority to operate the equipment, and invalidate the equipment's warranty.

*Operation of this device is subject to the following two conditions:*

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device".

### RF Exposure Warning

This unit is a radio transmitter designed to permit, produce and emit RF radiation into an antenna for the purpose of delivering RF to an appropriate receiving device.

The Maximum Permissible Exposure (MPE) limit for units of this type is 1.0mW/cm<sup>2</sup>. This low-powered device will generally not create RF exposure in excess of the MPE limits issued by the FCC (US) in OET Bulletin 65; 97-01, unless properly connected to an antenna, at which time the radiated power can exceed the MPE limits.

Antenna Gain	Min. Allowable Distance from Antenna @	
	5W Power	12W Power
0 dBi	20 cm	31 cm
5 dBi	35 cm	55 cm
16 dBi	126 cm	195 cm
30 dBi	631 cm	977 cm

The user is solely and exclusively responsible for determining the level of RF exposure when connecting the unit to an antenna or other equipment, taking appropriate steps to limit RF exposure, and for ensuring compliance with the FCC requirements in OET Bulletin 65.

© Copyrighted 2007, Nucomm, Inc., Hackettstown, New Jersey 08740