
Phone open

Microphone

Speaker - Microphone Front - Microphone Camera SIM Card Trav Volume Buttons Power Button (1) / Fingerprint Sensor @ Main Screen¹ (see "Take care of vour phone")

Phone back





With moto care, extend your warranty coverage up to three years. and take advantage of features like accidental damage protection. Visit:



motorola.com/motocare

(U.S. only, except P.R.)





XT2323-2

XT2323-5

XT2323-6



Speaker

² Wireless Charging: Charge your phone using a Qi-certified wireless charger (sold separately).








Put in a physical SIM card

Your phone supports using a physical SIM card.

- 1 With the phone closed and the external display facing down, insert the SIM tool into the tray hole to pop out the tray. Make sure you use a standard Nano SIM card and don't cut the SIM card.
- 2 Insert the SIM card with the gold contacts down, and the notch aligned with the card tray, then gently push the tray into the slot.



eSIM option: Your phone may have an eSIM (embedded SIM card) in addition to the physical SIM card. Contact your service provider for details if you want to activate and use it.

Power on and off

Press and hold the Power button to turn it on, then follow the prompts to get started.

Press the Power and Volume Up buttons at the same time to turn it off.

Take care of your phone 🔨

To guarantee your warranty service and ensure you have a satisfying phone experience, please care for your phone as follows:

- Don't use third-party screen protectors. Your phone comes with a Motorola-developed screen protector customized to Razr's unique foldable design. The Motorola screen protector is of superior quality and preserves the predicted service life of your phone. In contrast, using third-party screen protectors may reduce your phone's screen sensitivity, cause the main screen to become unresponsive, damage the screen, or cause other touch screen problems. In such cases, Motorola reserves the right to evaluate the situation and decide whether to provide you with free-of-charge warrafity service during the remaining warranty period.
- Contact an authorized Motorola service center if your screen protector has air bubbles, warps, or separates from the main screen during use.
 We may replace the screen protector because a compromised screen protector can damage the main screen and shorten the service life of the phone.
- Only replace your screen protector with Motorola-approved service personnel who use professional equipment. Don't replace the screen protector in service centers that Motorola doesn't authorize or try to remove or replace the screen protector yourself. This may damage the main screen and void the warranty.
- Take care not to physically damage your phone. Don't puncture or apply excessive force to the main screen with a hard or sharp object while carrying your phone. Before closing the phone, always ensure that there are no obstructions between the screens or hinges. Items such as cards, coins, keys, and other objects can damage your screen or prevent your phone hinge from closing properly. Don't use excessive force to press the middle area of the screen. Avoid exposing your phone to water, coffee, or other liquids. Also, don't expose your phone to tiny pieces of debris, such as grit.
- Important: This product contains magnets. Always keep products
 with magnets more than 20cm. (8 in.) from medical devices, such as
 pacemakers, internal cardio defibrillators, or other devices that can be
 affected by a magnetic field. Also, keep away from credit cards, ID cards,
 and other media that use magnetically encoded information.
- Protect your screen: Please do not rémove the attached screen protector or use third party screen protectors. Doing so will void the device warranty.
- Reminder: The crease at the bend on the main screen and the faint noise
 you may hear while flipping open the phone are part of the design and
 do not impact product durability.

Help & more

Get answers undates and info-

- Help is here: From the home screen, swipe up and tap Settings > Help to learn how to use your phone and get support.
- Get more: Get software, user guides, and more at
 www.motorola.com/myrazr.
- Get apps: Tap Play Store to browse and download apps.
- Ready For: Your phone works with Ready For, a new platform that extends your phone's experience to any compatible PC, TV, tablet, or monitor. To learn more, scan the QR code or visit www.motorola.com/ready-for.
- Connect with 5G: 5G service plan and 5G network coverage required; available only in select areas; device not compatible with all 5G networks. Contact your service provider for details.
- Legal Information. This guide provides important legal, safety, and regulatory information that you should read before using your product. For the complete legal information, from the home screen swipe up and tap Settings > Q, then type Legal information, or visit www.motorola.com/device-leval

Water repellent. Your phone is not waterproof. For more about your phone's water-repellent design and care, swipe up and tap Settings > Help.

Battery safety. To prevent possible burning and injury, the battery in your phone should only be removed by a Motorola-approved service center or similar skilled personnel.

If your phone becomes unresponsive, press and hold the Power button until the screen goes dark and your phone restarts. Charge your phone using a compatible Motorola charger (may be sold separately). Use of other chargers is not recommended and may impair the charging performance. Don't charge your phone in temperatures below. 20°C (-4°F) or above 45°C (13°F), Chargers that do not comply with applicable national standards may be unsafe, with risk of death or injury, and may cause slow charging or product damage. To view applicable standards and to learn more, see the "Legal information" section of this guide, or visit www.motorola.com/device-legal.

Warning about high volume usage. To prevent possible hearing damage, do not listen at high volume levels for long periods. When your headset volume reaches the high volume threshold, a warning shows. Tap **OK** to dismiss it, or wait one to five seconds, then press the Volume Up button to dismiss the alert and enable the volume to continue to be adjusted.

Disposal & recycling. For help recycling products and packaging responsibly, visit www.motorola.com/recycling.

Class 1 Laser. This device is classified as a Class 1 Laser

product, which is safe in normal use per IEC60825-1:2007
and IEC60825-1:2014. This device complies with 21 CFR
1040.10 and 1040.11, except for deviations pursuant to Laser Notice 50, dated
June 24, 2007. Do not attempt to modify or disassemble.

X

Extreme heat or cold. Don't use your phone in temperatures below -20°C (-4°F) or above 45°C ((13°F). Don't store/transport your phone in temperatures below -20°C (-4°F) or above 60°C (140°F).

Legal disclaimers. Features, services and applications are network

dependent and may not be available in all areas; additional terms/charges may apply. Product specifications and other information contained in this guide are believed to be accurate at the time of printing. Motorola reserves the right to correct or change any information without notice.

Arbitration. Your purchase is governed by a binding arbitration clause. For more information and how to opt-out, see the legal guide that came with your phone.

Copyright & trademarks, MOTOROLA, the stylized M logo, MOTO, and the MOTO family of marks are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. Google, Android, Google Play and other related marks and logos are trademarks of Google LLC. USB Type-C* and USB-C* are registered trademarks of USB Implementers Forum. All other product or service names are the property of their respective owners.

© 2023 Motorola Mobility ILC All rights reserved.

Product ID: (Model XT2323-2, XT2323-5, XT2323-6,)

