


HyperX Cloud Flight S

Wireless Gaming Headset

Quick Start Guide

Overview




- A** Up button — Mic monitoring toggle
- B** Left button — Game balance
- C** Right button — Chat balance
- D** Down button — Mic mute toggle
- E** Microphone port
- F** USB charge port
- G** Status LED
- H** Power button
- I** 7.1 Surround Sound button
- J** Volume wheel
- K** Detachable microphone
- L** Microphone mute LED
- M** USB adapter
- N** Wireless pairing pin hole
- O** Wireless status LED
- P** USB charge cable



440XXXX

1


Usage



1. Connect the wireless USB adapter to your device
2. Power on the headset

Setting up with PC


Right click speaker icon > Select Open Sound settings > Select Sound control panel




2

Playback Device


1. Set Default Communications Device to "HyperX Cloud Flight S Chat"



2. Set Default Device to "HyperX Cloud Flight S Game"




3. Right click on "HyperX Cloud Flight S Game" and click on Configure. Select 7.1 Surround to configure your setup and click next.



3


Recording Device

Set Default Device to "HyperX Cloud Flight S Chat"




Discord Voice Chat Software

- Set Input Device to "Microphone (HyperX Cloud Flight S Chat)"
- Set Output Device to "Headset Earphone (HyperX Cloud Flight S Chat)"



Setting up with PlayStation 4

1. Connect the wireless USB adapter to your device
2. Power on the headset



Settings > Devices > Audio Devices
 Input Device: USB Headset "HyperX Cloud Flight S"
 Output Device: USB Headset "HyperX Cloud Flight S"
 Output to headphones: All Audio

4


Status LED

STATUS	LED
Pairing	Flash Green and Red interactively every 0.5s
Searching	Slow breathing Green
Connected*	90% — 100%: Solid Green
	15% — 90%: Blinking Green
	< 15%: Blinking Red

*Battery level indication



Power button

Power on/off — Hold power button for 3 seconds



Game/Chat balance

Press to adjust mix between game audio and chat audio.¹




¹The game/chat balance functionality operates independently from the overall headset audio volume.

¹Game/chat balance function is unavailable when using headset on PS4.

Mic monitoring toggle


Press to toggle mic monitoring on/off



5

Microphone mute toggle

Press the microphone mute button to turn on/off the microphone mute. The microphone mute LED will indicate the current mute status.




MICROPHONE MUTE LED	MUTE STATUS
Solid	Mute on
Off	Mute off

7.1 Surround Sound*

Press to toggle 7.1 Surround on/off


* Virtual 7.1 surround sound effect output as a 2-channel stereo signal to be used with stereo headphones.



Volume wheel

Scroll up and down to adjust volume level.

WARNING: Permanent hearing damage can occur if a headset is used at high volumes for extended periods of time.



6

Charging

It is recommended to fully charge your headset before first use.


STATUS LED	CHARGE STATUS
Solid Green	Fully Charged
Breathing Green	15% — 99%
Breathing Red	< 15%

Qi Wireless Charging

Place left earcup on Qi wireless charging base.



Wired Charging



7

HyperX NGENUITY Software

To customize EQ profiles, programmable buttons, and check battery status, download the HyperX NGENUITY software at hyperxgaming.com/ngenuity



Questions or Setup Issues?

Contact the HyperX support team or see the user manual at hyperxgaming.com/support/headsets

8

Battery/TX Power Info

Battery Information
Contains 3.7 V, 1500 mAh Li-Ion Battery, 5.55Wh Cannot be replaced by user
Frequency & TX Power Information
Frequency Bands: 2.4GHz (TX Power: <2dBm)

FCC Compliance and Advisory Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

1. Reorient the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

Any special accessories needed for compliance must be specified in the instruction manual.

Warning:
A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used. Use only shielded cables to connect I/O devices to this equipment.

HyperX is a division of Kingston.
THIS DOCUMENT SUBJECT TO CHANGE WITHOUT NOTICE.
©2019 Kingston Technology Corporation, 17600 Newhope Street, Fountain Valley, CA 92708 USA.
All rights reserved. All registered trademarks and trademarks are the property of their respective owners.

CAUTION:
Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

Canada statement
Suppliers of radio apparatus shall provide notices and user information in both English and French:
This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.
This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Taiwan NCC Statement:
NCC / DGT 證照
第十二條：經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得得擅自變更頻率、加大功率或變更原設計之特性及功能。
第十四條：低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。
前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。