


# Quick Start Guide Ref. 1.0

HyperX Pulsefire Haste Wireless Mouse


## Overview



- A. Left click button
- B. Right click button
- C. Mouse wheel
- D. DPI button
- E. Forward button
- F. Back button
- G. USB-C port
- H. Optical gaming sensor
- I. Power switch
- J. Grip tape
- K. Mouse skates
- L. USB charge/data cable
- M. USB wireless receiver
- N. Wireless adapter

## **Charging**


It is recommended to fully charge your mouse before first use.



## **Installation**

### **Wireless Mode**

1. Connect the wireless receiver to the wireless adapter.
2. Connect the wireless adapter to a PC using the included USB cable and switch the mouse on. For optimal placement, keep the wireless receiver within 20cm of the mouse.



### **Wired Mode**

Connect the mouse to a PC using the included USB cable.

### **DPI Presets**

There are 4 default DPI presets: 400 DPI (red) | 800 DPI (blue) | 1600 DPI (yellow) | 3200 DPI (green)

### **HyperX NGENUITY Software**

To customize lighting, DPI, and macro settings, download the HyperX NGENUITY software at: [hyperxgaming.com/ngenuity](https://hyperxgaming.com/ngenuity)

[NGENUITY Bug]

### **Questions or Setup Issues**

Contact the HyperX support team or see the user manual at: [hyperxgaming.com/support/mice](https://hyperxgaming.com/support/mice)

## FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference,
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## 國家通訊傳播委員會(NCC)警語

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。