

## **SETUP PHOTOGRAPHS**

This document contains 10 photographs

**Photograph No.1**  
**Radiated emissions measurement setup in the anechoic chamber with loop antenna, USB configuration**



**Photograph No.2**  
**Radiated emissions measurement setup in the anechoic chamber with loop antenna, RS232 configuration**



**Photograph No.3**  
**Radiated emissions measurement setup in the anechoic chamber with loop antenna, USB configuration**



**Photograph No.4**  
**Radiated emissions measurement setup in the anechoic chamber with loop antenna, RS232 configuration**



**Photograph No.5**  
**Radiated emissions measurement setup in the anechoic chamber with biconilog antenna, USB configuration**



**Photograph No.6**  
**Radiated emissions measurement setup in the anechoic chamber with biconilog antenna, RS232 configuration**



**Photograph No.7**  
**Frequency stability test setup, USB configuration**



**Photograph No.8**  
**Frequency stability test setup, RS232 configuration**



**Photograph No.9**  
**Conducted emissions measurement setup, USB configuration**



**Photograph No.10**  
**Conducted emissions measurement setup, RS232 configuration**

