

Plotting for Conducted Emission

30M-1G




*RBW 100 kHz Marker 1 [T1]
*VBW 300 kHz -68.85 dBm
*SWT 500 ms 119.24000000 MHz

Ref -10 dBm

*Att 0 dB

1 PK
VIEW



Start 30 MHz

97 MHz/


Stop 1 GHz

1G-3G



Ref 20 dBm *Att 30 dB *RBW 1 MHz Marker 3 [T1]
*VBW 3 MHz -42.71 dBm
*SWT 500 ms 1.080000000 GHz

1 PK
VIEW




A

LVL

3G-8G



*RBW 1 MHz Marker 1 [T1]
*VBW 3 MHz -43.56 dBm
*SWT 500 ms 3.760000000 GHz




8G-13G



*RBW 1 MHz Marker 1 [T1]
*VBW 3 MHz -42.55 dBm
*SWT 500 ms 9.400000000 GHz

Ref 0 dBm *Att 20 dB

1 PK
VIEW



13G-19G




*RBW 1 MHz Marker 1 [T1]
*VBW 3 MHz -29.54 dBm
*SWT 500 ms 15.592000000 GHz

Ref 0 dBm

*Att 20 dB

1 PK
VIEW



Start 13 GHz

600 MHz/

Stop 19 GHz