



MODEL 3408 A1SHA1I6 1R2AASCA EF1DA1HR7OAC8AWQ4Q5Q8Q15xxxxxxxxx PXXXX

LEVEL TRANSMITTER S/N: 22GORK1234567 MFG DATE: 22/06 MADE IN SWEDEN

LT-01234567801234567801234567



CERTIFICATE HOLDER: ROSEMOUNT TANK RADAR AB; LAYOUTVÄGEN 1; 435 33 MÖLNLYCKE, SWEDEN

HART® 4-20 mA  
30 VDC 22.5 mA  
DEVICE REV: XXX  
PROTOCOL: XXXX  
HV/SV: 1.0.0/1.0.0 (1.A0)  
FCC ID: K8C3408L  
IC: 2827A-3408L  
HVIN: 3408L1

- FM21CA0083X  
INTRINSICALLY SAFE
- IS CLASS I, II, III DIV 1, GRPS A-G T4...T2
  - NI CLASS I, DIV 1, GRPS A-D T4...T2
  - S CLASS II, III DIV 2, GRPS E-G, T4...T2
  - CLASS 1 Zone 0 Ex ia IIC T4...T2 Ga
  - CLASS 1 Zone 0/1 Ex ib IIC T4...T2 Ga/Gb
  - Zone 20 Ex ia IIC T<sub>200</sub>...T<sub>200</sub> 250°C Da
  - Zone 20/21 Ex ib IIC T<sub>200</sub>...T<sub>200</sub> 250°C Da/Db (-55°C < Ta < +70°C), TYPE 4X / IP66/67/68
  - SINGLE SEAL -0.5...52 bar, -60°C...+200°C

WARNING/AVERTISSEMENT

SUBSTITUTION OF COMPONENTS MAY IMPAIR INTRINSIC SAFETY. POTENTIAL ELECTROSTATIC CHARGING HAZARD. LA SUBSTITUTION DE COMPOSANTS PEUT COMPROMETTRE LA SECURITE INTRINSEQUE. RISQUE POTENTIEL DE CHARGE ELECTROSTATIQUE. -SEE /VOIR LES INSTRUCTIONS. INSTALL PER CONTROL DRAWING / INSTALLER SELON LE SCHEMA DE CONTRÔLE D7000006-887

