## NOTES:

1. USE LABEL STOCK P/N LLR0040SP.

2 INSTALL ONTO PCB SHIELD COVER AS SHOWN.

| REVISION HISTORY |                         |             |            |                |  |
|------------------|-------------------------|-------------|------------|----------------|--|
| REV              | ECN                     | DESCRIPTION | DATE       | APPROVED       |  |
| Α                | 4037 PRODUCTION RELEASE |             | 2016-06-17 | J. STRANDQUIST |  |






LAB0011ZL

DRAFTER

**ENGINEER** 



## **APPROVALS** JACK STRANDQUIST CHECKED DEAN BUSCH

INFORMATION IN THIS DRAWING IS PROPRIETARY. IT IS ISSUED IN CONFIDENCE AND SHALL NOT BE USED AS A BASIS FOR MANUFACTURE WITHOUT WRITTEN PERMISSION FROM FREEWAVE TECHNOLOGIES.



FreeWave Technologies, Inc. 5395 Pearl Parkway Boulder, CO 80301

LAB0012ZL

TITLE

## LABEL, PRODUCT-LEVEL, **7UMI ÍNK 79-C AND 79-T**

| SIZE       | CACE CODE | CAGE CODE DWG NO.  105UA3 LAB0010ZL |              | RFV  |
|------------|-----------|-------------------------------------|--------------|------|
| SIZL       |           |                                     |              | KLV. |
| Α          | 05UA3     |                                     |              | A    |
| <i>-</i> \ |           |                                     |              | , ,  |
| SC         | ALE: NONE |                                     | SHEET 1 OF 1 |      |