
DC POWER CEILING FAN REMOTE CONTROL MANUAL

LEARNING PROCESS

NOTE: This unit is to be used for the control of DC power ceiling fan and in an AC110/120V 60Hz power supply only.

Step: 1 Open the remote battery cover and install CR2032*2pcs Lithium batteries.

Step: 2. Within 30 seconds of turning the Receivers AC power ON. use a ball pen to press and hold the Set key about 5 seconds.Once the receiver has detected the frequency, the receiver will make sound, Bi Bi, twice. This will indicate the receiver has learned the frequency that was previously selected on the transmitter.




Note: After the AC power is on, do not press any other button on the transmitter before setting learning. Doing so will cause the procedure to fail.

After completing the steps above, you should be able to operate the ceiling fan and light. If the fan is not responding to the transmitter, please turn the power off to the receiver. And repeat step 2.

LIGHT FUNCTION SELECT SWITCH

If installed energy light onto ceiling fan, please slide the dip switch, light function select switch, to "O" position. If installed tungsten light onto ceiling fan, please slide the "light function select switch" to "D" position.



FUCNCTIONS OF WALL REMOTE CONTROL

LED for show fan or light's function setting




FAN key : press and turn fan off



: fan speed control key

press the key 🗴 or key 💼 each time for change fan speed



ON/OFF- Press and release immediately to turn on or off dwon light.

DIMMER-Press 🗴 or sand hold to dim or brighten light to the desired level and

release

(Tungsten only and light function select switch on dimmer position.)



1hr: Setting up that the ceiling fan will turn off after 1 hour automatically3hr: Setting up that the ceiling fan will turn off after 3 hours automatically6hr: Setting up that the ceiling fan will turn off after 6 hours automatically

Home Shield – Press and hold the buttons for 3 seconds. Fan will be off and the light will randomly turn on and off while you are away home.



TR205A



X : Walk Away Light Delay – Tap once - the light and fan turn off after 1 minute automatically.



Press the key for set fan speed for making natural wind.



Press the key for forward airflow of ceiling fan

Touch icon for reverse airflow of ceiling fan.

To assure continued FCC compliance:

FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna. --Increase the separation between the equipment and receiver. --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

FCC ID:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.