

# GARAGE DOOR REMOTE CONTROL

## USER'S INSTRUCTIONS

(MODEL : CSL-2)

### PROGRAMMING YOUR NEW TRANSMITTER

1. Open the case with a corn.
2. For code setting:  
With the receiver unit plugged in the AC outlet, press and hold the 'learn' button on the receiver and its LED light will flash. Then press the button on the transmitter until the receiver light stops flashing indicating it has learned the code.
3. Test the receiver unit with the transmitter.

### LIGHT

Press the case to emit the light.

### BATTERY

One 3 volt Lithium type (CR2032) battery included.

### WARNING

If this transmitter triggers other garage doors in your neighborhood, change all your transmitters and receiver to a new code setting.

<p>DO NOT let children use the garage door transmitter without adult supervision. Children can injure themselves or others by the garage door.</p>
--

### WARRANTY

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase is required.

### FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

### WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed

and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### CUSTOMER SERVICE

Skylink will not be liable or responsible for any misuse or application of this product other than for its intended use.

If you would like to order Skylink's products or have difficulty getting them to work, please :

1. visit our FAQ section at [www.skylinkhome.com](http://www.skylinkhome.com) or
2. email us at [support@skylinkhome.com](mailto:support@skylinkhome.com) (reply within 24 hours) or
3. call our toll free at 1-800-304-1187 from Monday to Friday, 9am to 5pm EST. Fax +800-286-1320

17 Sheard Avenue, Brampton, Ontario, Canada L6Y 1J3  
<http://www.skylinkhome.com>

© 2005 SKYLINK TECHNOLOGIES INC.