



RBW 3 MHz


\* VBW 3 MHz

SWT 50 ms

Ref -20 dBm

\* Att 0 dB

1 PK \*  
CLRWR



SGL

Duty Cycle  
=  $[34(0.4) + 44(0.2)] / 100$   
=  $(13.6 + 8.8) / 100$   
= 0.224

Average Factor  
=  $20 \log 0.224$   
= -13dB

Center 389.84 MHz

5 ms/




RBW 3 MHz      Delta 1 [T1 ]  
\*VBW 3 MHz      0.18 dB  
SWT 200 ms      106.000000 ms

Ref -20 dBm

\*Att 0 dB

1 PK \*  
CLRWR



Marker 1 [T1 ]  
-44.63 dBm  
106.000000 ms

\*  
A  
SGL

Center 389.84 MHz

20 ms/



RBW 3 MHz

\* VBW 3 MHz


SWT 10 ms

Ref -20 dBm

\* Att 0 dB

1 PK \*  
CLRWR

\*  
A  
SGL



Center 389.84 MHz


1 ms/



RBW 3 MHz      Marker 1 [T1 ]  
\*VBW 3 MHz      -46.06 dBm  
SWT 2 s      676.000000 ms

Ref -20 dBm      \*Att 0 dB

1 PK \*  
VIEW



Center 389.84 MHz

200 ms/