




RBW 3 MHz Marker 1 [T1]
* VBW 3 MHz -33.71 dBm
SWT 2 s 941.500000 ms

Ref -20 dBm

*Att 0 dB

1 PK *
VIEW



Duty Cycle
= 100 / 100
= 1

Average Factor
= 20 log 1
= 0dB

Center 299.782 MHz

200 ms/



RBW 3 MHz

* VBW 3 MHz


SWT 35 ms

Ref -20 dBm

* Att 0 dB

1 PK *
CLRWR

*
A
SGL



Center 299.782 MHz

3.5 ms/