### 1. INTRODUCTION

In this package, you will find a Skylink Remote transmitter with 3V lithium battery. The Remote transmitter allows you to operate the Skylink's receiver.

There are four buttons on the transmitter MKA-315, each button can be programmed to control Skylink receiver.

### 2. PROGRAM THE TRANSMITTER TO RECEIVER

In order for the remote control to communicate with the receiver, the transmitter must be programmed to the receiver. Follow the brief instructions below to program transmitter to the receiver you want to control.

Refer to the receiver user's instructions to set up the unit.

- 1. Press the Learn button on the receiver unit.
- 2. Once the learn button is pressed, the receiver LED will flash quickly. Release the Learn button.
- 3. Press any one of the 4 buttons on the transmitter that you want to program to the receiver
- 4. Once the transmitter is programmed, the receiver LED will flash slowly.
- 5. You may now operate the receiver with this new transmitter.

### 3. OPERATION

Press the button for 1 second and release, this will activate the "learned" Skylink receiver(s).

#### 4. BATTERY

The remote control operates on one 3-volt lithium battery that is installed at the factory. Dispose of used battery properly according to the instructions.

#### 5. WARRANTY

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase is required.

## 6. FCC statement

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

#### 7. IC

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### 8. CUSTOMER SERVICE

If you would like to order Skylink's products or have difficulty getting them to work, please :

- 1. visit our FAQ section at www.skylinkhome.com, or
- 2. email us at <a href="mailto:support@skylinkhome.com">skylinkhome.com</a>, or
- 3. call our toll free at 1-800-304-1187 from Monday to Friday, 9am to 5pm EST. Fax (800) 286-1320.

# SKYLINK TECHNOLOGIES INC.,

17 Sheard Avenue, Brampton, Ontario, Canada L6Y 1J3

Email: <a href="mailto:support@skylinkhome.com">skylinkhome.com</a>
Website: <a href="http://www.skylinkhome.com">http://www.skylinkhome.com</a>

© 2014 Skylink Group