




**Channel Move Time, Channel Closing Transmission Time for Type 2 radar**


**Channel 5500MHz**





**Channel Move Time, Channel Closing Transmission Time for Type 3 radar.**


**Channel 5260MHz**





**Channel Move Time, Channel Closing Transmission Time for Type 3 radar.**


**Channel 5500MHz**





**Channel Move Time, Channel Closing Transmission Time for Type 4 radar.**


**Channel 5260MHz**





**Channel Move Time, Channel Closing Transmission Time for Type 4 radar.**

**Channel 5500MHz**





**Channel Move Time, Channel Closing Transmission Time for Type 5 radar.**


**Channel 5260MHz**





**Channel Move Time, Channel Closing Transmission Time for Type 5 radar.**

**Channel 5500MHz**






Measure the UUT for more than 30 minutes following the channel close/move time to verify that the UUT does not resume any transmissions on this Channel.

**30 Minute Non-Occupancy Period (using Type 1 radar)**

**Channel 5260MHz**







**30 Minute Non-Occupancy Period (using Type 1 radar)**

**Channel 5500MHz**

