




Channel 1 (30MHz - 1GHz)




Channel 1 (1GHz - 3GHz)




# Channel 1 (3GHz-6GHz)




Channel 1 (6GHz-12GHz)




## Channel 1 (12GHz-18GHz)




Channel 1 (18GHz-25GHz)







Channel 7 (1GHz - 3GHz)




# Channel 7 (3GHz-6GHz)




Channel 7 (6GHz-12GHz)




## Channel 7 (12GHz-18GHz)




Channel 7 (18GHz-25GHz)









Channel 14 (1GHz-3GHz)




# Channel 14 (3GHz-6GHz)



Channel 14 (6GHz-12GHz)



## Channel 14 (12GHz-18GHz)



Channel 14 (18GHz-25GHz)