

# CLiK64-T User Instructions

1. Press the button on the key tag transmitter for at least **one second** to transmit the signal code. A red indicator light will flash for the duration of the transmission. Pressing and holding the button down only transmits one pulse. This reduces unintentional transmissions and conserves battery life.
2. Release and press the button for one second again to send another transmission.
3. If the light on the transmitter does not light up when you press and hold any button, replace the battery.

CLiK64-T-P1



CLiK64-T-P2



CLiK64-T-P3



CLiK64-T-P4



# CLiK64-T Battery Replacement

1. Carefully pry open the case with a flat edge tool or screwdriver from the key ring corner.



2. Make sure the case is laid flat on the table upside down.
3. Push the coin shaped battery out of its holder and replace it with a CR2032 battery being careful to place the "+" positive side on top.



4. DO NOT install the batteries backwards. The device will be damaged.
5. Snap close the case
6. Test the transmitter and look for the red LED light to flash when a button is pressed for one second.

# CLiK64-T Label Placement



Place label in outlined area





This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### **WARNING**

Changes or modifications not expressly approved by Active Control Technology Inc. could void the user's warranty and authority to operate the equipment.

#### **Active Control Technology Inc.**

3200 Ridgeway Drive, Unit 17  
Mississauga, Ontario,  
Canada, L5L 5Y6  
905-670 5500  
[www.activecontrol.com](http://www.activecontrol.com)