


# BAP1200 Function

- **Panel figure:**



- **Key Function:**

- On/off : Start/Stop this unit system.
- Speed : Adjust air purify fan speed .Its have hi , mid , low , sleep , auto controller function , This key is valade when unit system on.
- Set : for set “timer”,”clock”,”alarm key”.
- Timer :
  - Press Timer& Set key at same time can enter timer mode and LCD will show “TIMER” symbol.
  - First setting auto off timer mode when system in on. First seting hour(it will flash) then after setting minute(it will flash).After setting auto off time’s hour and minute.
  - When press “speed” key system will auto cancel timer mode.
  - When system in off user can setting auto on time.
  - Hold presstime key over 2 second cancel timer mode.可取消定時功能。
- Clock :
  - Press Clock& Set key at same time setting real time clock.
  - Press clock key change clock display mode.

## BAP1200 Function

- Alarm :
  - Press Alarm& Set key at same time setting alarm time. And it will appear bell symbol on the LCD.
  - When alarm bell symbol will flash and buzzer will continue beep. User press alarm key buzzer will stop. And user need press alarm and set key at same time to cancel alarm mode and bell symbol will disappear..
  - Press alarm key change alarm time display mode
- Up : When enter setting time it can increase time.
- Down : When enter setting time it can decrease time.
- Sensor : sense room brightness for control backlight.
  - When user press key backlight will on after 5 second backlight will auto off.
  - Press up&down key backlight will continue on or switch to off.
  - When room bright from light change to dark backlight will auto on.
  
- PARTICLE SENSOR function.
  1. PARTICLE SENSOR need place above ground 1meter.
  2. Speed control table in auto mode.

LED									
SPEED	Sleep	Low	Low	Mid	Mid	Mid	Hi	Hi	Hi

### Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.