


Transmitter: TP36RF315



SPEC

Power: AAA battery*2

Distance: 40 feet(air)

Frequency: RF 315MHz fixed frequency

ID: 65535 sets

Dim: DIP SW ON ==> Light Dimmer, DIP SW OFF ==> Light ON / OFF

FAN Function

OFF KEY: fan off

HI KEY: fan high speed

MED KEY: fan medium speed

LO KEY: fan low speed

LIGHT Function

LIGHT KEY: Light on/off or dimmer

Receiver: RL-142

SPEC

Power: 120V/60 HZ
Frequency: RF 315 MHZ
FAN: Hi-Med-Lo 3 speeds
LIGHT: Light On/Off or dim is controlled by Transmitter DIP SW

FAN Function

Hi: Fan runs in high speed and the receiver long beeps for 3 times.
Med: Fan runs in medium speed and the receiver long beeps for 2 times.
Low: Fan runs in low speed and the receiver long beeps for 1 times.
Off: Fan stops running and the receiver beeps for 4 times.

LIGHT Function

Non-dim mode:

Light runs only full on and off.
The receiver short beeps for one time.
This mode is only used for CFL bulb.

Dim mode:

Light can be dimmed.
It dims from lightest to lowest back and forth.
When the light is the brightest or lowest, it short beeps for 2 times.
This mode is not suitable for CFL bulb.

FAN & LIGHT Memory Function

The receiver would memorize the fan speed and bulb brightness.
If in Dim mode, the brightness of the bulb would be memorized in the receiver.
When the AC power is turned off for more than 2 seconds and back to work, the fan speed and bulb will recover.

Automatic Pairing

The receiver and transmitter pair each other automatically.
By learning process, the receiver memorize the transmitter code in build-in memory automatically.

Learning process:

In one minute when the receiver first time gets powered, press and hold the Off button on the transmitter for about 5 seconds.
The receiver beeps for 4 times to complete the learning process.
The pairing is done and you can start to use it

Federal Communication Commission Interference Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Non-modification Statement:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.