



Quick Start Guide

Duo™
wireless mouse

www.ablenetinc.com

Updated: March 17, 2020 4:35 PM

Use with Bluetooth Connection

1. Remove the USB wireless receiver from the bottom of the Duo wireless mouse and store it in a safe place. The USB wireless receiver is not used with a Bluetooth connection, but would be used if a device does not have Bluetooth.
2. Open Bluetooth settings on device you are pairing mouse to.
3. Insert 2 AAA batteries into Duo wireless mouse.
4. Move Duo wireless mouse mode switch towards the Bluetooth icon to turn on Bluetooth mode.
5. Activate Bluetooth pairing button on Duo wireless mouse for 5-seconds and then release.
6. On your device, select ANDUO from the list of Bluetooth devices available.
7. Move the mouse to ensure the mouse cursor on your device moves.

Note: If storing mouse, remove batteries.



Use with USB Wireless Receiver

1. Remove the USB wireless receiver from the bottom of the Duo wireless mouse. Insert the USB wireless receiver into a USB Type A port on the device you will be using.
2. Insert 2 AAA batteries into Duo wireless mouse.
3. Move Duo wireless mouse mode switch towards the USB wireless receiver icon to turn on USB wireless mode.
4. Move the mouse to ensure the mouse cursor on your device moves.

Note: If storing mouse, remove batteries.

Use with Accessibility Switches

Connect one or two AbleNet accessibility switches with 1/8-in (3.5-mm) plugs to the Duo wireless mouse to control the left or right mouse clicks.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.