

Operation:

Installation

The Pendant operates on three 1.5V batteries. The life of those batteries for standby is approximately 3 years. There are two screws on the back of the transmitter that hold the top and bottom case together.

Recommendation: Test your transmitter periodically to ensure that all the batteries are working. If the communication distance or the brightness of alarm LED reduced, please replace all batteries with new one.

To replace the Pendant batteries:

1. Undo the two screws on the back of the transmitter. The bottom case will then come off.
2. Take out all the old batteries using a small screwdriver or a pen
3. Place the new batteries in position.
4. Reprogram the device if necessary.
5. Close the battery cover and reinsert two screws.

Programming

Pendant allows you to activate WR-1 or WR-2 receivers after programming shown below.

1. Press and hold the "SETUP" button of the Receiver unit until the "SETUP" LED lights up.
2. Press the "ALARM" button of Pendant once, the alarm LED will light up (or flash slowly for first setup).
3. Plug the program cable to Base unit and Pendant, LED will quickly flash to indicate connection successfully.
4. Select one of 16 locations in sequence by pressing "SETUP" button (for WR-1, WR-2).
5. Press and hold "SETUP CONFIRM" button to assure. The "SETUP" LED on Base unit will turn off and "ALARM" LED on transmitter will turn off once if installation successfully.
6. Disconnect the program cable; alarm LED of Pendant turn off.
7. Press the "ALARM" button of Pendant once, the corresponded unit LED on Base unit will light up and alarm will hear.
8. Repeat step 2~7 for other Transmitters.

Operation

In an emergency, you can activate the WR-1 or WR-2 receivers using the Pendant. Press the "ALARM" button once will transmit alarm to receiver for around 2.5 minutes to activate the receivers. To release the alarm on receiver, press the "ALARM RESET" button on the receiver to turn off the alarm sound and corresponded unit LED.

FCC Warning

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.