

Instruction Manual Bluetooth Speaker



Thank you for purchasing your new Q18P. We recommend that you spend some time reading this instruction manual in order that you fully understand all the operational features it offers.

Read all the safety instructions carefully before use and keep this instruction manual for future reference.

SAFETY PRECAUTIONS

Check that the voltage marked on the rating label matches your mains voltage.

Avoid extreme degrees of temperature, either hot or cold.

Place the unit well away from heat sources such as radiators or gas/electric fires.

Avoid exposure to direct sunlight and other sources of heat.

Charge the speaker at least once within three months to prevent the lithium battery from being damaged by excessive consumption.

Always disconnect the unit from the mains power supply before connecting/disconnecting other devices or moving the unit.

Unplug the unit from the mains power socket during a lightning storm.

Package Contents

Bluetooth Speaker x 1

Type C Cable X 1

Aux In Cable x 1

Instruction Manual x 1

Technical Data

Bluetooth Version: 5.0

Impedance: 4Ω

Output : 12.5W*2

Battery: 7.2V 2000mAh

Voltage: DC 5V

Size: 188*73.5*73.5mm

Product Overview

1. “⏻”

Long press: Power on/off

Short press: Play/Pause

2. “⦿”

Battery status LED indicator

3. “+”

Short press: Volume increase

Long press: Next track

4. “= ”

Short press: Volume decrease

Long press: Previous track

5. “⏸” (TWS button)

6. “⦿”

Working status LED indicator




7. “⚡”

Short press: Move to bluetooth mode

Answer/hang up the call

Long press: Reject the call

8.





Charging Q18P Speaker


1. Connect to a PC/Laptop or any 5V USB adaptor with the USB cable included.
2. The Battery status LED will turn ON Yellow and keep blink to show you the electronic quantities. The battery indicator stays on after full charged.
3. Unplug the USB cable when fully charged.

Note: Speaker will prompt “DUDU” tune when the battery power is low (<15%).



Starting Q18P speaker

1. After fully charged, long press the “  ” button to turn on the speaker.
2. The Blue LED will start blinking.
3. It will turn itself off (power-saving)if idle for more than 20 minutes.
4. To manually turn off Q18P speaker, long press the “  ” button again.

Bluetooth Operation

1. Turn on the speaker, the Blue LED will start blinking.
2. Turn on the Bluetooth function of your mobile device and look for “TRENDY” in the Bluetooth device list.
3. After successfully connected the speaker will prompt a tone and the Blue LED will stop blinking.
4. Long press the “  ” button to disconnect the current Bluetooth connection. The speaker will prompt a tone and the Blue LED will start blinking.


Hands-free phone calls

1. Make sure the mobile phone is paired.
2. Press the “  ” button to answer the incoming phone call.
3. Press again to end the call.
4. Long press the “  ” button to reject the incoming phone call.

AUX IN Operation

1. Turn on the speaker, the Blue LED will start blinking.
2. Disconnect the paired mobile device with the speaker if they have been paired.
3. Use the 3.5mm audio cable provided to connect the speaker to an audio source.
4. You can play music from the audio source.

Note:


Short press the “  ” button during AUX IN operation, the speaker will move to Bluetooth mode.



You have to unplug and re-connect the audio cable to the speaker again to enter AUX IN mode.

The previous/next track button do not work during AUX IN mode.

Press the Play/Pause button to mute the speaker during music playback in AUX IN mode.

TWS(True Wireless Stereo) Pairing



1. Turn on two Q18P speakers and disconnect any paired Bluetooth devices.
2. Short press the “  ” button of one of the speakers, this speaker will become “MASTER” speaker and search another “SLAVE” speaker for pairing up to 60 seconds.
3. After TWS paired, the “MASTER” speaker will prompt a sound , the LED of “SLAVE” speaker will change to solid Green and the Blue LED of “MASTER” speaker will blink.
4. Connect your Bluetooth device to the “MASTER” speaker.
5. You can now play music with True Wireless Stereo (TWS) function on both speakers.
6. Long press “  ” button for 2 seconds again to disconnect TWS pairing.

Troubleshooting

Problem	Solution
No Power	Recharge the speaker.
No Sound	<ol style="list-style-type: none"><li data-bbox="660 591 1267 622">1. Adjust the volume on the connected device.<li data-bbox="660 631 1299 707">2. Make sure that your Bluetooth device is within the effective operational range.
Cannot find the pairing ID "Q18P" on the Bluetooth device	<ol style="list-style-type: none"><li data-bbox="660 770 1353 846">1. Ensure the Bluetooth function is activated on your Bluetooth device.<li data-bbox="660 855 1353 931">2. Make sure that your Bluetooth device is within the effective operational range.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.