

User Instruction Manual

Gateway Installation:

1. Connect the Gateway to the internet via the supplied Ethernet cable. Use a port on the internet modem or router labeled with “LAN” or “Ethernet”. Power the Gateway.
2. Connect the supplied USB cable to the power adaptor (5V), plug the smallest connector of the USB cable in the gateway.
3. Insert the power adaptor in a power outlet. The device will turn on and several lights start to blink. When the power light stays continuously on, the device is ready

Gateway LED direction:

1. Green LED - Power light, and show the Ethernet connect is normal or not;
2. Orange LED - Pairing & Zigbee
3. Red LED - Error




ethernet (1) and USB port (2)




lights on the gateway (3)

PIR Sensor Installation:


1. Open the casing by detaching the back plate from the device. Place the AA batteries inside the sensor; Close the casing, you will hear a “click” when done properly.
2. Drill a hole in the wall at about 1.4 meters high. Use the provided wall plug to turn the screw in the wall.
3. Mount the sensor by sliding the hole in the top of the back plate over the screw in the wall. Make sure the lens is pointing upwards.



opening the casing



battery
placement




wall mounting



proper orientation

Door/window Sensor Installation:

1. Place the sensor body and magnet on door or window by double-sided tape on the back.
Make sure the dots on both devices are close to each other.
2. The gap of door or window must less than 10mm



FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.