


Your **HTC** Media Link HD

User guide



htc
quietly brilliant

This user guide will help you get started with your HTC Media Link. In this guide, we use the following symbols to indicate important or useful information:



Notes



Important information



Tips



Safety precaution

For the complete user guide and other helpful resources, check out the HTC support website at www.htc.com/support.

Please also read the Safety and regulatory guide that's included in the box.


Contents

What's in the box	3
Getting to know HTC Media Link	3
Turning on HTC Media Link	4
Using your home network for sharing media	6
Using the Media Link app	9
Troubleshooting tips	10
Trademarks and copyrights	11

What's in the box

Here's what you should find when you open the box:

- HTC Media Link
- microUSB cable
- HDMI cable
- This user guide
- Safety and regulatory guide

 The EUT should be supplied by USB port from complied Limited Power Source of personal computer or notebook. The EUT should be supplied by Adapter from complied Limited Power Source. Rating:5VDC,1A.

Getting to know HTC Media Link

Do you have a crowd squinting behind to watch that cool video on your phone? Use HTC Media Link to show it on your big screen TV. Share photos and music, too.

What's more, you can also turn your phone into a remote control to browse and play media from a Microsoft Windows® 7 computer straight to your TV screen.

Before using HTC Media Link, make sure that you have:

- a DLNA®-compatible HTC phone
- an HDMI®-supported TV
- a Windows 7 computer (if you want to stream media from your computer to your TV)

4 HTC Media Link




Turning on HTC Media Link

1. Attach the power plug to the power adapter.
2. Plug the power adapter into the USB connector on the top side of your HTC Media Link.
3. Plug in the power adapter to an electrical outlet.

Connecting your TV to HTC Media Link

1. Plug the HDMI cable into the HDMI connector on the top side of your HTC Media Link.
2. Connect the other end of the HDMI cable into your TV.



3. On your TV, choose HDMI as input setting.
You'll then see the HTC Media Link screen on your TV.



Checking the device status

The LED indicator shows:

- Solid red light when HTC Media Link is on standby mode.
- Solid Blue light when HTC Media Link is providing a hotspot or is connected to a home network.

Using your home network for sharing media

If you have a home network, you can simply use it to connect your TV (through HTC Media Link), your phone, and your Windows 7 computer for sharing media files.



Using this setup, you'll be able to:

- Share media from your phone to your TV.
- Wirelessly access media on a Windows 7 computer right from your phone, and share them to your TV.

Connecting HTC Media Link to your home network

Press and hold the POWER button on HTC Media Link for around three seconds. HTC Media Link then scans for available Wi-Fi networks. You'll then see your connection settings update on the bottom part of the TV screen.


If this is your first time to connect the device to your home network, please open the configuration tool in your web browser (see "Accessing the configuration tool using a web browser") and set up the connection (see "Changing your Wi-Fi connection").

Once you've set up the connection, you just need to press and hold POWER on HTC Media Link whenever you want to connect it to your home network.

Connecting your phone to your home network

Connect your phone to your home network either through your phone's Wi-Fi settings or by downloading and using the Media Link app. (To find out about how to use the app, see "Using the Media Link app".)












1. From your phone's Home screen, press MENU, and then tap **Settings**.
2. Tap **Wireless & networks**, and then select the **Wi-Fi** check box to turn Wi-Fi on. The phone then scans for available wireless networks.
3. Tap **Wi-Fi settings**.
4. In the **Wi-Fi networks** section, select your home network.
5. Enter the password when prompted.

Once your phone is connected to a wireless network, the Wi-Fi icon  appears in the status bar.

To find out how to play media to your TV, see "Sharing media from your phone to your TV".

Controlling media playback from your phone


When you're playing media from your phone to your TV, use the following controls on your phone's Controller screen to control the playback.

Controls	To
	Play the media on your TV.
	Pause the music or video playback.
	Play the previous photo or music track.
	Play the next photo or music track.
	Shuffle your music playlist.
	Select a repeat mode for photos or music tracks.
	Show available media that you can share.
	View the media information such as the file name, title, and duration.
	Connect to another photo/video player on the network.
	Connect to another music player on the network.
	Adjust the volume of the video or music you're playing on the other device.
	Disconnect your phone from the other device. Until you disconnect the phone from the other device, other media that you open from the Gallery or Music app are shared on the other device.


Using the Media Link app

Connected or confused? Use the Media Link app to easily connect and switch between the HTC Media Link hotspot and your home network.



Downloading and installing the Media Link app

1. From your phone's Home screen, tap , and then tap HTC Hub.
2. Search for the Media Link app.
3. Tap the app to download and install it on your phone.

Connecting to a network using the Media Link app

1. Make sure that HTC Media Link is turned on.
2. From your phone's Home screen, tap , and then tap Media Link.

Your phone automatically connects to the network that HTC Media Link currently uses.

3. To check the current network connection status, tap .
4. To connect to the HTC Media Link hotspot directly, tap .
5. If you want to select another network, press MENU > Change current network, and then tap the network you'd like to connect to from the list.

Troubleshooting tips

If you ever have any problems using HTC Media Link, here are some things you can do to set things right again.

- Still seeing a blank screen after connecting HTC Media Link to your TV? Do the following:
 - Check if the LED indicator light on HTC Media Link is green. If not, press the POWER button to switch the device to active status.
 - Check if the HDMI cable is properly connected to the device and to your TV.
 - Check if you have selected the correct HDMI input as your TV's input setting.
- Can't connect your phone to HTC Media Link? Check if your phone has the correct data connection.
 1. On the Home screen, press MENU, and then tap **Settings**.
 2. Tap **Wireless & networks**, and check if you have selected the Wi-Fi check box.
 3. Tap **Wi-Fi settings**, and check if you have selected **HTC Media Link**.
- Problem streaming a media file to your TV? Wait a few seconds more. Bigger files take longer to buffer.
- Having an error? Turn off HTC Media Link by unplugging it from the power adapter. Plug it in again and press the POWER button to restart it.
- Check for additional updates and useful tips on our website: www.htc.com/support.

Trademarks and copyrights

Copyright © 2010 HTC Corporation. All Rights Reserved.

The HTC logo, the HTC quietly brilliant logo, HTC Media Link, and HTC Hub are trademarks and/or service marks of HTC Corporation.

Microsoft, Windows, and Windows Media are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Wi-Fi is a registered trademark of the Wireless Fidelity Alliance, Inc.

DLNA is a registered trademark, DLNA disc logo is a service mark, and DLNA Certified is a trademark of the Digital Living Network Alliance.

All other company, product and service names mentioned herein are trademarks, registered trademarks or service marks of their respective owners.

HTC shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from furnishing this material. The information is provided "as is" without warranty of any kind and is subject to change without notice. HTC also reserves the right to revise the content of this document at any time without prior notice.

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or storing in a retrieval system, or translated into any language in any form without prior written permission of HTC.



91H0xxxx-xxM Rev.A

HTC Media Link HD DG H200

Safety and
regulatory guide

htc
quietly brilliant

Please read before proceeding

YOUR WARRANTY IS INVALIDATED IF YOU DISASSEMBLE OR ATTEMPT TO DISASSEMBLE THE DEVICE.

Limitation of damages

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL HTC OR ITS AFFILIATES BE LIABLE TO YOU, ANY USER, OR THIRD PARTY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, INCIDENTAL OR PUNITIVE DAMAGES OF ANY KIND, ARISING IN CONTRACT, TORT, OR OTHERWISE, INCLUDING, BUT NOT LIMITED TO, INJURY, LOSS OF REVENUE, LOSS OF GOODWILL, LOSS OF BUSINESS OPPORTUNITY, LOSS OF DATA, AND/OR LOSS OF PROFITS, REGARDLESS OF THE FORESEEABILITY THEREOF OR WHETHER HTC OR ITS AFFILIATES HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. AND IN NO EVENT SHALL THE TOTAL LIABILITY OF HTC OR ITS AFFILIATES EXCEED THE AMOUNT RECEIVED FROM YOU, REGARDLESS OF THE LEGAL THEORY UNDER WHICH THE CAUSE OF ACTION IS BROUGHT. THE FOREGOING DOES NOT AFFECT ANY STATUTORY RIGHTS WHICH MAY NOT BE DISCLAIMED.

Important health information and safety precautions

When using this product, the safety precautions below must be taken to avoid possible legal liabilities and damages.

Retain and follow all product safety and operating instructions.

Observe all warnings in the operating instructions on the product.

To reduce the risk of bodily injury, electric shock, fire, and damage to the equipment, observe the following precautions.

Electrical safety

This product is intended for use when supplied with power from the designated power supply unit. Other usage may be dangerous and will invalidate any approval given to this product.

Safety precautions for proper grounding installation

CAUTION: Connecting to improperly grounded equipment can result in an electric shock to your device.

The plug must be plugged into an appropriate outlet which is properly installed and grounded in accordance with all local codes and ordinances.

Safety precautions for power supply unit

- **Use the correct external power source**

A product should be operated only from the type of power source indicated on the electrical ratings label. If you are not sure of the type of power source required, consult your authorized service provider or local power company. For a product that operates from battery power or other sources, refer to the operating instructions that are included with the product.

This product should be operated only with the following designated power supply unit(s).

AC adapter:

HTC, Model TC C250, TC U250, TC E250, TC A250, TC K250, and TC B250.

- **Take extra precautions**

- Keep the device dry and away from water or any liquid as it may cause a short circuit.
- Keep metal objects away so they don't come in contact with the connectors as it may lead to short circuit during operation.

Safety precautions for direct sunlight

Keep this product away from excessive moisture and extreme temperatures. Do not leave the product inside a vehicle or in places where the temperature may exceed 60°C (140°F), such as on a car dashboard, window sill, or behind a glass that is exposed to direct sunlight or strong ultraviolet light for extended periods of time. This may damage the product or pose a risk to the vehicle.

Safety in aircraft

Due to the possible interference caused by this product to an aircraft's navigation system and its communications network, using this device on board an airplane is against the law in most countries.

Environment restrictions

Do not use this product in gas stations, fuel depots, chemical plants or where blasting operations are in progress, or in

4 Safety and regulatory guide

potentially explosive atmospheres such as fuelling areas, fuel storehouses, below deck on boats, chemical plants, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles, such as grain, dust, or metal powders. Please be aware that sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Explosive atmospheres

When in any area with a potentially explosive atmosphere or where flammable materials exist, the product should be turned off and the user should obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Users are advised not to use the equipment at refueling points such as service or gas stations, and are reminded of the need to observe restrictions on the use of radio equipment in fuel depots, chemical plants, or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. These include fueling areas, below deck on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

Interference with medical equipment functions

This product may cause medical equipment to malfunction. The use of this device is forbidden in most hospitals and medical clinics.

If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Turn your device OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Hearing aids

Some digital wireless devices may interfere with some hearing aids. In the event of such interference, you may want to consult your service provider, or call the customer service line to discuss alternatives.

Electrical safety

- Accessories
 - Use only approved accessories.
 - Do not connect with incompatible products or accessories.
 - Take care not to touch or allow metal objects, such as coins or key rings, to contact or short-circuit the terminals.
- Faulty and damaged products
 - Do not attempt to disassemble the device.
 - Only qualified personnel must service or repair the device.

General precautions

You alone are responsible for how you use the device and any consequences of its use. Use of the device is subject to safety measures designed to protect users and their environment.

- **Device getting warm after prolonged use**

When using your device for prolonged periods of time, the device may become warm. In most cases, this condition is normal and therefore should not be interpreted as a problem with the device.
- **Heed service markings**

Except as explained elsewhere in the Operating or Service documentation, do not service any product yourself. Service needed on components inside the device should be done by an authorized service technician or provider.
- **Protect your device**
 - Always treat your device and its accessories with care and keep them in a clean and dust-free place.
 - Do not expose your device or its accessories to open flames or lit tobacco products.
 - Do not expose your device or its accessories to liquid, moisture or high humidity.
 - Do not drop, throw or try to bend your device or its accessories.
 - Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
 - Do not paint your device or its accessories.
 - Do not attempt to disassemble your device or its accessories, only authorised personnel must do so.
 - Do not expose your device or its accessories to extreme temperatures, minimum -20 and maximum 50 degrees Celsius.
 - Please check local regulations for disposal of electronic products.

6 Safety and regulatory guide

- Do not carry your device in your back pocket as it could break when you sit down.

- **Damage requiring service**

Unplug the product from the electrical outlet and refer servicing to an authorized service technician or provider under the following conditions:

- Liquid has been spilled or an object has fallen into the product.
- The product has been exposed to rain or water.
- The product has been dropped or damaged.
- There are noticeable signs of overheating.
- The product does not operate normally when you follow the operating instructions.

- **Avoid hot areas**

The product should be placed away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

- **Avoid wet areas**

Never use the product in a wet location.

- **Avoid using your device after a dramatic change in temperature**

When you move your device between environments with very different temperature and/or humidity ranges, condensation may form on or within the device. To avoid damaging the device, allow sufficient time for the moisture to evaporate before using the device.

NOTICE: When taking the device from low-temperature conditions into a warmer environment or from high-temperature conditions into a cooler environment, allow the device to acclimate to room temperature before turning on power.

- **Avoid pushing objects into product**

Never push objects of any kind into cabinet slots or other openings in the product. Slots and openings are provided for ventilation. These openings must not be blocked or covered.

- **Mounting accessories**

Do not use the product on an unstable table, cart, stand, tripod, or bracket. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

- **Avoid unstable mounting**

Do not place the product with an unstable base.

- **Use product with approved equipment**
This product should be used only with personal computers and options identified as suitable for use with your equipment.
- **Cleaning**
Unplug the product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning, but NEVER use water to clean the device.
- **Small children**
Do not leave your device and its accessories within the reach of small children or allow them to play with it. They could hurt themselves or others, or could accidentally damage the device. Your device contains small parts with sharp edges that may cause an injury or which could become detached and create a choking hazard.
- **Operating machinery**
Full attention must be given to operating the machinery in order to reduce the risk of an accident.

Regulatory agency identifications

For regulatory identification purposes, your product is assigned a model number of DG H200.

NOTE: This product is intended for use with a certified Class 2 Limited Power Source, rated 5 Volts DC, maximum 1 Amp power supply unit.

CE 0984 

Federal Communications Commission notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or TV reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

The user for Indoor operation in the 5150 – 5250 MHz band.

Exposure to Radio Frequency Radiation:

To comply with FCC RF exposure compliance requirements, a separation distance of at least 20cm must be maintained between the antenna of this device and all persons. This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Industry Canada Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This Category II radiocommunication device complies with Industry Canada Standard RSS-210.

Ce dispositif de radiocommunication de catégorie II respecte la norme CNR-310 d'Industrie Canada.

The device could automatically discontinue transmission in case of absence of information to transmit, or operational failure. Note that this is not intended to prohibit transmission of control or signaling information or the use of repetitive codes where required by the technology.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IMPORTANT NOTE:

IC Radiation Exposure Statement

This EUT is compliance with SAR for general population/uncontrolled exposure limits in IC RSS-102 and had been tested in accordance with the measurement methods and procedures specified in IEEE 1528. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

The County Code Selection feature is disabled for products marketed in the US/ Canada.)

Modifications

The FCC requires the user to be notified that any changes or modifications made to the device that are not expressly approved by HTC Corporation may void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement

- This Transmitter has been demonstrated co-location compliance requirements with WLAN.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

- This equipment complies with FCC RF radiation exposure limit set forth for an uncontrolled environment.

WEEE notice

The Directive on Waste electrical and Electronic Equipment (WEEE), which entered into force as European law on 13th February 2003, resulted in a major change in the treatment of electrical equipment at end-of life.


The purpose of this Directive is, as a first priority, the prevention of WEEE, and in addition, to promote the reuse, recycling and other forms of recovery of such wastes so as to reduce disposal.



The WEEE logo (shown at the left) on the product or on its box indicates that this product must not be disposed of or dumped with your other household waste. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste. Isolated collection and proper recovery of your electronic and electrical waste equipment at the time of disposal will allow us to help conserving natural resources. Moreover, proper recycling of the electronic and electrical waste equipment will ensure safety of human health and environment. For more information about electronic and electrical waste equipment disposal, recovery, and collection points, please contact your local city center, household waste disposal service, shop from where you purchased the equipment, or manufacturer of the equipment.

RoHS compliance

This product is in compliance with Directive 2002/95/EC of the European Parliament and of the Council of 27 January 2003, on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS) and its amendments.



91H0xxxx-xxM Rev.A