



Date: 21.SEP.2009 09:40:45



Date: 21.SEP.2009 09:41:27



Ref -20 dBm      \*Att 0 dB      RBW 3 MHz      Delta 1 [T1 ]  
 VBW 10 MHz      -48.68 dB  
 SWT 100 ms      100.000000 ms



A  
 SGL  
 TRG


Duty Cycle  
 = 0.196 ms  
 100  
 = 0.00196

Average Factor  
 = 20log(0.00196)  
 = -54.15dB

Date: 21.SEP.2009 09:42:20



Ref -20 dBm      \*Att 0 dB      RBW 3 MHz      Marker 1 [T1 ]  
VBW 10 MHz      -31.83 dBm  
SWT 1 ms      196.000000  $\mu$ s



Date: 21.SEP.2009 09:43:32