


Date: 15.JUL.2009 09:30:42



Ref -20 dBm Att 10 dB RBW 1 MHz Marker 2 [T1]
 VBW 3 MHz -43.37 dBm
 SWT 100 ms 53.400000 ms



A
 SGL
 TRG

Duty Cycle
 $= \frac{2 \times (0.196) \text{ ms}}{100}$
 $= 0.00392$


Average Factor
 $= 20 \log(0.00392)$
 $= -48 \text{ dB}$

Date: 15.JUL.2009 09:34:12



RBW 1 MHz Delta 1 [T1]
VBW 3 MHz 0.16 dB
SWT 2 ms 196.000000 µs

Ref -20 dBm Att 10 dB



Date: 15.JUL.2009 09:35:10