




RBW 1 MHz
*VBW 1 MHz
SWT 2 s

Ref -20 dBm

Att 10 dB

1 PK
VIEW



Center 2.45736 GHz

200 ms/




RBW 1 MHz Delta 1 [T1]
*VBW 1 MHz 0.04 dB
SWT 500 ms 246.000000 ms

Ref -20 dBm

Att 10 dB

1 PK
VIEW



Duty Cycle

= 0.194 / 100

= 1.94×10^{-3}

Average Factor

= $20 \log (1.94 \times 10^{-3})$

= -54 dB

Center 2.45736 GHz


50 ms/



RBW 1 MHz Delta 1 [T1]
*VBW 1 MHz 0.68 dB
SWT 1 ms 194.000000 μ s

Ref -20 dBm Att 10 dB

1 PK
VIEW



Center 2.45736 GHz

100 μ s/