




RBW 3 MHz    Delta 1 [T1 ]  
\*VBW 3 MHz    -36.22 dB  
SWT 100 ms    100.000000 ms

Ref -20 dBm    Att 10 dB

1 PK  
VIEW



Duty Cycle  
 $= \frac{62 \times 0.46 + 15 \times 0.94}{100}$   
 $= 0.426$   
Average Factor  
 $= 20 \log 0.426$   
 $= -7.4 \text{ dB}$

Center 433.94 MHz

10 ms/




RBW 3 MHz    Delta 1 [T1 ]  
\*VBW 3 MHz    -0.06 dB  
SWT 200 s    53.200000 s

Ref -20 dBm

Att 10 dB

1 PK  
VIEW



A

3DB

Center 433.94 MHz

20 s/




RBW 3 MHz      Delta 1 [T1 ]  
\*VBW 3 MHz      -0.04 dB  
SWT 92 ms      89.424000 ms

Ref -20 dBm

Att 10 dB

1 PK  
VIEW



Center 433.94 MHz


9.2 ms/



RBW 3 MHz    Delta 1 [T1 ]  
\*VBW 3 MHz    0.13 dB  
SWT 10 ms    460.000000 μs

Ref -20 dBm    Att 10 dB

1 PK \*  
VIEW



Center 433.94 MHz


1 ms/



RBW 3 MHz      Delta 1 [T1 ]  
\*VBW 3 MHz      0.18 dB  
SWT 10 ms      940.000000 μs

Ref -20 dBm      Att 10 dB

1 PK \*  
VIEW



3DB

Center 433.94 MHz

1 ms/