

0623338




RBW 3 MHz
*VBW 3 MHz
SWT 100 ms

Ref -20 dBm

Att 10 dB

1 PK *
CLRWR



Center 433.8957666 MHz

10 ms/

Duty Cycle
SGL = 0.5

Average Factor
= $20 \log 0.5$
= -6.0 dB

0623338




RBW 3 MHz
*VBW 3 MHz
SWT 20 ms

Ref -20 dBm

Att 10 dB

1 PK*
CLRWR



Center 433.8957666 MHz

2 ms/

0623338




RBW 3 MHz
*VBW 3 MHz
SWT 10 ms

Ref -20 dBm

Att 10 dB

PK *
CLRWR

SGL



Center 433.8957666 MHz

1 ms/

062338




RBW 3 MHz Marker 1 [T1]
*VBW 3 MHz -43.77 dBm
SWT 200 ms 93.200000 ms

Ref -20 dBm

Att 10 dB

1 PK *
CLRWR



SGL

Center 433.8957666 MHz

20 ms/

0623338




RBW 3 MHz Delta 1 [T1]
*VBW 3 MHz -0.03 dB
SWT 100 s 73.000000 s

Ref -20 dBm

Att 10 dB

1 PK *
CLRWR



Center 433.8957666 MHz

10 s/

SGL