




RBW 3 MHz
* VBW 3 MHz
SWT 100 ms

Ref -20 dBm *Att 10 dB

1 PK *
CLRWR



*
A
SGL

Duty Cycle
= [14(1.0) + 74(0.5)] / 100
= 51 / 100
= 0.51

Average Factor
= 20 log (0.51)
= -5.8 dB

Center 433.962 MHz

10 ms/



RBW 3 MHz


* VBW 3 MHz

SWT 10 ms

Ref -20 dBm

* Att 10 dB

1 PK *
CLRWR



Center 433.962 MHz

1 ms/




RBW 3 MHz Marker 1 [T1]
*VBW 3 MHz -38.42 dBm
SWT 500 ms 109.200000 ms

Ref -20 dBm

*Att 10 dB

1 PK *
CLRWR

A
SGL
TRG



Center 433.962 MHz

50 ms/




RBW 3 MHz Delta 1 [T1]
*VBW 3 MHz 0.01 dB
SWT 100 s 14.000000 s

Ref -20 dBm

*Att 10 dB

1 PK *
VIEW



Center 433.962 MHz

10 s/