

Notice:

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INFORMATION

The Federal Communication Commission Radio Frequency Interference Statement includes the following paragraph:

The equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication.

However, there is no grantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice:

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE:

To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted.


Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.


FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.


This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.





1. **MIC1 Wired Microphone Input (XLR /  $\Phi$ 6.3mm)**  
Connect a wired microphone here.
2. **MIC / LINE Switch**  
Switches the signal level of the MIC1 wired microphone input between MIC and LINE.
3. **MIC1 Wired Microphone Volume Control**  
Adjusts the volume for MIC1.
4. **MIC2 Wired Microphone Input ( $\Phi$ 6.3mm)**  
Connect a second wired microphone here.
5. **MIC2 Wired Microphone Volume Control**  
Adjusts the volume for MIC2.
6. **Echo Effect Switch and Control**  
Adjusts the echo effect for both the wireless digital receiver module and wired microphone signals.
7. **Voice Priority Function Switch**  
Pressing this button will illuminate the voice priority indicator light, prioritizing the output of wireless digital receiver module and wired microphone signals, while suppressing other audio sources.
8. **Voice Priority Indicator Light**  
Shows the status of the voice priority function.
9. **USB Power Port**  
Used for charging the GX 7 H / GX 7 T.
10. **Master Volume Control**  
Adjusts the output volume of all mixed input sources.
11. **Treble Control**  
Adjusts the treble quality of all mixed input sources. When centered, it maintains the original sound.
12. **Bass Control**  
Adjusts the bass quality of all mixed input sources. When centered, it maintains the original sound.
13. **Bluetooth Status Light**  
Indicates the Bluetooth connection status.
14. **Bluetooth Function Switch**  
Bluetooth Function Switch
15. **AUX Input / Bluetooth Volume Control**  
Adjusts the volume for AUX input and Bluetooth.
16. **AUX Input ( $\Phi$ 3.5mm)**  
Connects external audio sources.
17. **AUX Output ( $\Phi$ 3.5mm)**  
Provides output for external amplifiers or other PA systems.
18. **Battery Level Indicator Light**  
Charging: Running lights  
Fully Charged: Green FULL light on  
Low Battery: Red light flashing if battery is below 20%, indicating the need to charge soon.
19. **DC Power Input Socket**  
For connecting the DC power supply.
20. **Passive Speaker Connection Socket**  
Used to connect to passive speaker.



1. **LCD Screen**
2. **Infrared Receiver**
3. **USB Flash Drive Slot**
4. **SD Card Slot**
5. **Power Switch:** Long press for 1.5 seconds to turn the digital music module on or off.
6. **MP5 Function Control Area**