


Content / Inhalt / Contenu / Inhoud / Contenido



Installation / Montage / Fitting / Bevestiging / Instalación



1 multiremote parts

The **multiremote** has three buttons, which are marked with the symbols (▲, ● and ▼). Additionally there is a red/green LED located at the center.

To mount the remote control a handlebar adapter and various rubber rings are provided.

2 Mounting of multiremote

The **multiremote** can be mounted on the left or on the right side of a handlebar.

To achieve correct key assignment, please refer to „Adjusting the assembly side“ of this manual once the **multiremote** has been mounted.

3 Turning the multiremote on

To activate the remote control press the center button. Once the remote is activated, the status LED is flashing periodically.



4 Adjusting the assembly side of the bar

Assembly on the left side of the handlebar

After you have installed the **multiremote** on the left side, please press and hold the upper and middle buttons (▲ and ●) for about 2 seconds.

Once the Status LED turns green for 2 seconds, the remote control is set to the left side of the handlebar.

Assembly on the right side of the handlebar

After you have installed the **multiremote** on the right side, please press and hold the upper and middle buttons (▲ and ●) for about 2 seconds.

Once the Status LED turns red for 2 seconds, the remote control is set to the right side of the handlebar.

5 Pairing

Please refer also to the User's Guide of your head unit (App or ANT+™ device) to ensure that the pairing mode is activated if needed. To find compatible apps please refer to our homepage.

1. Bring the **multiremote** in the near (1m) of the head unit.
2. Please press and hold the upper and lower button (▲ and ▼) for about 2 seconds until the Status LED lights flashes green and red together for 2 seconds.
3. Now the **multiremote** is looking for a head unit (Status LED flashes green and red together).
4. If required, follow the specific instructions for „pairing“ in the User's Guide of your head unit.
5. Once the Status LED is flashing green, the **multiremote** is connected to the head unit successfully.

6 Turn your multiremote off

The **multiremote** will switch automatically to standby mode after up to 150 seconds, when the head unit is no longer activated.

7 Replacing the battery

If the Status LED flashes during operation periodically red, the battery is almost completely drained and should be replaced.

The battery of the **multiremote** can be changed without special knowledge and by using a 50 Euro cent coin. For this purpose, a standard CR2032 battery is required, which is inserted into the new remote control.

8 Overview of Status LEDs

LED flashing green: **multiremote** is ready to use and connected to the head unit.

Flashing green and red together: **multiremote** is ready to use but searches for the „paired“ head unit.

- a) Please bring the head unit within the transmission range (1m).
- b) Devices are not paired. Please see chapter „pairing“.

LED flashing red: Battery weak

Please replace the battery.

No flashing even though button press: Battery completely discharged

Please replace the battery.

Electromagnetic Interferences: Disturbance may occur near electrical devices such as LED lights, motors or electrical brakes. Also WLAN access points may cause interference when using **multiremote**. To avoid problems move away from possible sources of disturbance.

9 Technical specifications

Dimensions: 48 x 38 x 21 mm (L x W x H)
 Weight: ca. 15g (incl. CR2032 battery)
 Water resistance: 1m
 Compatibility: ANT+, Bluetooth® 4.0
 Radio frequency: 2,4 GHz ANT™, Bluetooth® 4.0
 Transmission range: 3m
 Operating temperature: -10°C – 60°C
 Battery: CR2032 Lithium Battery.
 Battery lifetime: up to 100 hours operating

10 Warranty

We are only liable for damages in accordance to the statutory regulations in respect to our contractual partners. Batteries are excluded from warranties. In case of a warranty please contact the retailer where you purchased your device. Batteries may not be disposed of with the regular household.



11 FCC STATMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE

The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.