

**TROUBLESHOOTING** For more troubleshooting and tips, visit [www.MeboRobot.com](http://www.MeboRobot.com)

PROBLEM	SOLUTION
Mebo is not responding	<ul style="list-style-type: none"> <li>• Ensure battery is charged and properly plugged into connector.</li> <li>• Check to see if Wi-Fi is enabled on your smart device.</li> <li>• Mebo may be out of Wi-Fi range.</li> </ul>
Mebo's part (s) aren't moving	<ul style="list-style-type: none"> <li>• Inspect MEBO's joints, claw and wheels for foreign objects.</li> </ul>
Unable to connect to Mebo through WiFi	<ul style="list-style-type: none"> <li>• If after several attempts you are unable to connect to Mebo through your device's Wi-Fi, press <b>RESET</b> for 5 seconds on the underside of Mebo using the tip of a pin. After reset, try connecting again.</li> </ul>

**WARNING**

- This product is intended primarily for indoor use or on surfaces clear of dirt or water.
- Do not immerse the product in water as this is hazardous and can cause product to malfunction.
- Keep fingers and hands away from all moving parts and joints including arm and wheels.
- Keep the camera clean, and wipe with a lint-free cloth.
- Remove battery when not in use for long periods as it will reduce the life span and performance of the battery.
- When a charger is not in use, disconnect it from the power source.
- Do not leave the battery connected to a charger for longer than one day. Overcharging may shorten battery life.
- If left unused a fully charged battery will discharge itself over time.
- Charging time may vary in countries where there is major fluctuation.
- The charger is not a toy. Do not use extension cords with the charger.
- Use under adult supervision only. Do not use if there is any visible damage to the cord, housing or other moveable parts.

**THIS PRODUCT CONTAINS A LITHIUM-POLYMER BATTERY 7.4V 1350mAh:**

- LiPo batteries have a severe risk of fire and injury if they are improperly handled or misused. They may explode, overheat or ignite.
- Read all following precautions and instructions regarding the care and use of LiPo batteries.
- The built-in LiPo battery is only to be used with the drone and charger included with this product.
- Keep away from flammable materials.
- Do not expose to direct sunlight.
- Do not place in fires or leave in hot places.
- Do not drop or make subject to strong impact.
- Keep dry and away from water.
- Remove exhausted batteries as soon as possible and discard properly.
- Remove all batteries from the compartment if toy is not used for a long period.
- The supply terminals are not to be short circuited.
- Never throw batteries in a fire or attempt to open outer casing.
- LiPo Battery Disposal: LiPo batteries must be recycled or disposed of properly. They should not be disposed of with other household waste.
- Check your local laws and regulations for correct recycling and/or battery disposal.

This device complies with PART 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna - Increase the separation between the equipment and receiver - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected - Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

**Questions or comments?**  
Please call 888-674-5650 or email  
[support@skyrockettoys.com](mailto:support@skyrockettoys.com)

01604

Remove all packaging attachments before giving the toy to a child. Not suitable for children under 3 years due to small parts that could be swallowed. Conforms to product safety standards ASTM F963. Keep instructions for future reference. Do not discard.




©2016 Skyrocket Toys LLC, Los Angeles CA 90066 USA. All Rights Reserved. Sky Viper and Skyrocket and their respective logos are trademarks and/or registered trademarks of Skyrocket Toys LLC. All other trademarks, logos and copyrights are the property of their respective owners, and there is no relationship express or implied with Skyrocket Toys LLC.

# mēbo™

AGES 8+

**CONTENTS: MEBO ROBOT, LIPO BATTERY & CHARGER**

SMART PHONE OR TABLET REQUIRED (NOT INCLUDED).




SYSTEM REQUIREMENTS: Works with most Apple iOS and Android Devices, WiFi Connection.

CONTENTS: Mebo Robot, LiPo Battery, and Charger

**CHARGING MEBO'S BATTERIES**

1. Plug battery into wall charger.
2. Plug wall charger into power outlet.
3. Charge until battery is completely charged.
4. Unplug battery from charger and charger from power outlet.




**RED LIGHT = Charging**

**GREEN LIGHT = Fully Charged**

**IMPORTANT**

- Adult supervision is required for charging LiPo battery.
- After use, allow battery to cool down to room temperature before charging again.
- Charge battery in an isolated area, away from excessive heat or moisture.
- If you suspect battery is damaged or swelling, discontinue charging and use immediately and discard according to local regulations.
- Do not modify, heat or wet the battery in any way.
- Only recharge with the charger provided.

**ATTACHING MEBO'S WHEELS**



Mebo's wheels must be attached before use.

- Carefully align the grooves on the wheel hubs with the wheels and snap into place.
- Once wheels have been attached, they should not be removed.

**#MeboDidIt**

Hop online and check out what Mebo's been up to!

[www.MeboRobot.com](http://www.MeboRobot.com)



## GETTING STARTED

### 1. INSTALLING MEBO'S BATTERY

- Open the battery compartment on the back of Mebo.
- Plug the battery into the enclosed connector. Rest the battery inside and close the compartment door.

### 2. DOWNLOAD THE MEBO APP

- Download the **MEBO** app and install onto your smart phone or tablet.



### 3. TURN MEBO ON


- Flip the power switch on the back of Mebo to turn on. Mebo's eye will light up and flash when turned on.

### 4. CONNECT WITH YOUR SMART DEVICE

- Enable the Wi-Fi on your phone or tablet and select **MEBO-xx-xx-xx** (name of connection may differ slightly from this example on your Wi-Fi network list).
- Mebo's eye will stop flashing when successfully connected to Wi-Fi.
- Once connected please follow in App instructions.



### CONTROL MEBO FROM ANY ROOM IN YOUR HOUSE!

You can control Mebo from even further away in your house by connecting through your home Wi-Fi instead of your device's Wi-Fi. Go to **Wi-Fi Connections** in your app settings for details.



## MEBO SPECS


\*Mebo's lift capacity should not exceed 250g



### RESET MEBO'S WIFI CONNECTION

- If Mebo is unresponsive OR if Mebo has been set to connect to a Wi-Fi network that is no longer available, you may need to press **RESET** to clear and reset Mebo.
- **RESET** can also be used to clear a Wi-Fi password if you have forgotten it.
- Use a pin or unfolded paperclip to press the **RESET** button and hold for 5 seconds.


## MEBO CONTROLS



Menu may vary from image shown.

## P2P REMOTE WIFI CONNECTION

### CONTROL MEBO FROM ANYWHERE



See from Mebo's point of view through your smart phone or tablet and you can control him discretely from another room. With an internet connection, you can even control him from a friend's house down the street or the other side of the world! See app for details.

## **IC RSS warning**

This device complies with Industry Canada licence-exempt RSS standard (s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that, the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

IC Radiation Exposure Statement:

This equipment complies with IC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

ICES003 :

This CAN ICES3 (B)/NMB3(B) digital apparatus complies with Canadian ICES003.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

IC exposition aux radiations:

Cet équipement est conforme avec IC les limites d'exposition aux rayonnements définies pour un contrôlé environnement.

Cet émetteur ne doit pas être co-localisés ou fonctionner en conjonction avec une autre antenne ou émetteur.

Cela peut CIEM 3 (B) / NMB 3 (B) Cet appareil numérique est conforme à la norme NMB 003.