

Print data (Front side)

POZZI

Turbo

QUICK START GUIDE

Box content:

1 x Mobile Phone	1 x Power Adapter
1 x Quick Start Guide	1 x Type C Cable
1 x Safety Information	1 x SIM Tray Ejector Pin
1 x Wired Stereo Headset	1 x Lithium Polymer Battery
1 x Protective Case	

Charging the battery

Before using the device for the first time or when the battery has been unused for extended periods, you must charge the battery.

CAUTION : Use only POZZI-approved chargers, batteries, and cables. Unapproved chargers or cables can cause the battery to explode or damage the device.

The charging port is located at the bottom edge of the phone. Connect your charger to the wall outlet and then connect your charger to the right position of charging port.

After charging, disconnect the device from the charger. Unplug the charger from the device at first, and then unplug it from the electric socket.

Checking the battery charge


When you charge the battery while the device is off, press the Power key to view the current battery charge status.

To check the charging status while the device is on, you should see charge symbol in the top right-hand corner.

Turning the device on and off

Press and hold the Power key for a few seconds to turn the device on and off.

Phone Layout



Network Compatibility

2G: GSM 850 / 900 / 1800 / 1900

3G: 850 / 1700 / 1900

4G: LTE Bands 2 / 3 / 4 / 5 / 7 / 12 / 17 / 28AB / 66 / 71

If you have issues connecting the phone to your mobile network, please verify if you have active service with your mobile service provider and you are within its network coverage area or contact your mobile service provider directly.

Installing the SIM card(s) and SD card

The Turbo supports two nano SIM cards or one nano SIM and one SD memory card.

Use the SIM card(s) provided by the supported GSM mobile telephone service provider.


① Turn off the phone.

② Insert the included pin tool in the hole and push to eject the SIM tray.



③ The SIM card tray will be pulled out, then take it out.

④ Insert Nano SIM 1 and Nano SIM 2 or SD Card into the tray with the metal terminal side down.



⑤ Insert the SIM card tray straight.

⑥ When you turn on the power, your Nano SIM card is recognized.

Setting up cellular data

- ① Go to the application menu, and look for Settings
- ② Tap on 'Network & Internet' and then 'SIMs'
- ③ Choose on the name of the mobile phone carrier
- ④ Tap the empty check box to the right of "Mobile data" (This will put a green check in the "Mobile data")
- ⑤ LTE displays on the top of the screen.

In case of "LTE" "3G" or "E" missing on the top of the screen, or you sign up with a Mobile Virtual Network Operator (MVNO) which operates on big carriers, you might need to configure your phone's APN settings.

Note: The APN Settings are unique combination of values, please contact your mobile phone carrier for the newest APN as this differ from network operator to network operator.

To get started configuring APN settings:

- ① Go to the application menu, and look for Settings
- ② Tap on 'Network & Internet' and then 'SIMs'
- ③ Choose on the name of the mobile phone carrier
- ④ Tab on Access Point Names (bottom row)
- ⑤ Tab "+" sign to create a new APN

Accessing more information

Visit <http://www.hiPozzi.com> to view device information, the user manual, troubleshooting and more.

Google is a trademark of Google LLC.

Print data (back side)

POZZI

Turbo

Guía de inicio rápido

Contenido incluye

1 x Teléfono	1 x Cargador de pared / USB
1 x Guía de inicio rápido	1 x Cable tipo C
1 x Seguridad de la información	1 x Sim Bandeja Pasador De Expulsión
1 x Auriculares estéreo con cable	1 x Batería de polímero de litio

Cargando la batería

Antes de usar el dispositivo por primera vez o cuando la batería no se ha utilizado durante períodos prolongados, debe cargar la batería.

PRECAUCIÓN : Use solo cargadores aprobados por POZZI, Baterías y cables. No aprobado cargadores o cables pueden causar la batería explotar o dañar el dispositivo.

El puerto de carga se encuentra en la parte superior, borde del teléfono. Conecta tu cargador a la toma de corriente y luego conecte su cargador a la po conexión del puerto de carga.

Después de cargar, desconecte el dispositivo de el cargador. Desenchufe el cargador del dispositivo al principio, y luego desenchufelo del toma de corriente.

Comprobación de la carga de la batería


Cuando cargue la batería mientras el dispositivo está apagado, presione la tecla Encendido para ver el estado actual de carga de la batería.

Para verificar el estado de carga mientras el dispositivo está encendido, deberías ver esto símbolo en la esquina superior derecha.

Encender y apagar el dispositivo

Encender y apagar el dispositivo Mantenga presionada la tecla Encendido durante unos segundos para encender y apagar el dispositivo.

Dispositivo del teléfono



Compatibilidad de red

2G: GSM 850 / 900 / 1800 / 1900

3G: 850 / 1700 / 1900

4G: Bandas LTE 2 / 3 / 4 / 5 / 7 / 12 / 17 / 28AB / 66 / 71

Si tiene problemas para conectar el teléfono a su red móvil, verifique si tiene un servicio activo con su proveedor de servicios móviles y si se encuentra dentro del área de cobertura de su red, o comuníquese directamente con su proveedor de servicios móviles.

Instalación de la (s) tarjeta (s) SIM y SD

Turbo admite dos tarjetas nano SIM o una tarjeta nano SIM y un tarjeta de memoria SD.

Utilice la(s) tarjeta(s) SIM proporcionada(s) por el móvil GSM compatible proveedor de servicios telefónicos.


① Apaga el teléfono.

② Inserte la herramienta pin incluida en el agujero y empujar para expulsar la bandeja SIM.



③ La bandeja de la tarjeta SIM se sacará, luego saque la.

④ Inserte la tarjeta Nano SIM 1 y Nano SIM 2 o SD en la bandeja con el lado del terminal metálico hacia abajo.



⑤ Inserte la bandeja de la tarjeta SIM en línea recta.

⑥ Cuando enciende la alimentación, se reconoce su tarjeta Nano SIM.

Configurar datos celulares

- ① Vaya al menú principal y mire para la configuración
- ② Toque en 'Red e internet' y toque 'Red móvil'
- ③ Toque el nombre del teléfono móvil operador
- ④ toque la casilla de verificación vacía a la derecha de "Datos móviles". (Esto pondrá una marca verde en "Datos móviles"
- ⑤ Celular LTE Los datos deben estar activos.

Si los datos celulares están habilitados, pero el "4G", "3G", o "E" no se muestra en la parte superior de la pantalla o te registras con un operador de red virtual móvil (MVNO), cuya red opera en grandes operadores, es posible que deba ponerse en contacto con el operador y configurar el APN de su teléfono configuración

APN es una combinación única de valores, por favor comuníquese con su operador para obtener el APN más nuevo, ya que esto difiere de la red operadora a operador de red.

Para comenzar a configurar APN:

- ① Vaya al menú principal y mire para la configuración
- ② Toque en 'Red e internet' y toque 'Red móvil'
- ③ Toque el nombre del teléfono móvil operador
- ④ Pestaña sobre nombres de puntos de acceso (fila inferior)
- ⑤ Pestaña "+" para crear un nuevo APN

Accediendo a más información

Lea el Manual del usuario o visite <http://www.hiPozzi.com> para ver la información del dispositivo, el manual del usuario, solución de problemas y más.

Google es una marca registrada de Google LLC C.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

SAR Information Statement

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is **0.401W/Kg** and when worn on the body, as described in this user guide, is **1.156W/Kg** (Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). The maximum scaled SAR in hotspot mode is **1.156W/Kg**. While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID: **OCVPOZ02ZITBO**. Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at <http://www.wow-com.com>. * In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of **10mm** must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.