

# User Manual

Remote control instruction

off/on

to get into standby when power on

Long Press to 2S –on / Long Press to 2S off

Press it -stop

Waiting for accessing the host after power on ,  
access to working set when host reachable.

10 minutes after host unreachable, it will access to working set again Long press on/off button it will access to working set .

Black screen is Screen saver .

Screen lit up when press any button.

It will go into Screen saver again when no any operation after 30 seconds .

Motors :

1. Scan : Motor Scan, Regarding current location to be the original , Motor mount start to turn left 90 degree (3S) then turn right 180 degree (6S). then stop after turning left 90 degree (3S) .

1. PAN\_LEFT, motor mount turn left
2. PAN\_RIGHR, motor mount turn right
3. DECOY\_ON/OFF: Decoy on/off button
4. DECOY Speed choice/high speed/middle speed/low speed  
High speed - stop 3 seconds - rotate 20 seconds in forward direction- stop 3 seconds-reverse 20 seconds  
Middle speed - stop 3 seconds- rotate 10 seconds in forward direction -stop 3 seconds-reverse 10 seconds  
Low Speed=stop 3 seconds- rotate 5 seconds in forward direction -stop 3 seconds-reverse 5 seconds

AUX: ON; AUX:OFF; on/off status will be showed on the screen

Voice:

- 1 PLAY\_PAUSE , Play or Stop selected songs**
- 2 VOL\_UP ; VOL\_DOWN ;**
- 3 RECALL: Recall to play previous song**
- 4 F1/F2/F3/F4/F5 : :Long press for 2seconds**  
EEPROM remember currently played sound file and volume. 5 location to store the favourite sound .Press will play memorial songs . Button no memory no response . ( Default F1 button when first time power on , remember the first song. F2-F5 no memory no response .
- 5 Video**

- a. RECORD\_STOP: Record on/off
- b. PIC: Press button will be photographed function  
This function will be without when video.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.