



OontZ XL

User Manual

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

INDUSTRY CANADA

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

safety

- a. CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- b. A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- c.  Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions – All the safety and operating instructions should be read before this product is operated.
2. Keep these instructions – The safety and operating instructions should be retained for future reference.
3. Heed all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow all instructions – All operating and use instructions should be followed.
5. Do not use this apparatus near water – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool, and the like.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacture's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at the plugs, convenience receptacles, and at the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart or rack is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



13. Unplug the apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



- This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.
- The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.

Introduction

What is Bluetooth technology

Bluetooth® is a wireless technology that enables wireless data communication over a short range between digital devices. In general, Bluetooth-enabled devices connect wirelessly with each other within a range of 32 feet (10m).

In order for two Bluetooth-enabled devices to work together wirelessly to perform a certain function, both devices should be compatible with the same Bluetooth profile that supports this function.

Introduction to OontZ XL

Thank you for purchasing our product.

This is a Bluetooth wireless speaker system that supports Bluetooth version 2.1.

This device is compatible with the following Bluetooth profiles:

A2DP - Advanced Audio Distribution Profile


AVRCP - Audio/Video Remote Control Profile

HFP - HandsFree Profile

With this device, you can:

- Play music from a Bluetooth enabled mobile phone or audio source that is compatible with A2DP, such as an iPod/iPhone/iPad, Android smartphone, PC, or Mac.
- Use the device as a speaker phone for a Bluetooth connected mobile phone.
- Play music from an auxiliary device connected through the supplied 3.5mm audio cable.
- Charge your portable device such as an MP3 player or mobile phone through the USB socket on the back panel.

Overview



1. DC power socket

Connect the power adapter.

2. 5V USB OUT

Charge a portable device through a USB charging cable (not supplied).

3. AUX IN

Connect an auxiliary device.

4. Microphone

5. Indicator

Indicate the recharge status of the built-in battery.

6. Indicator

Indicate the Bluetooth pairing status.

7/8. /

In Bluetooth mode, press to skip to the previous or next song.

9/10.-/+

Turn down/up volume.

11. Button

During play in Bluetooth mode:

(Press) pause or resume music play.

(Press and hold) remove the existing pairing information.

(Press) answer/hang up a call for a Bluetooth connected mobile phone.

(Press and hold) reject during a call for a Bluetooth connected mobile phone.

12. Button

Press once to turn on the device.

In power-on mode, press and hold to turn off the device

During music play, press to mute or resume sound output.


Unpack

Unpack and identify the items of your package:

- 1 x Bluetooth wireless speaker
- 1 x power adapter
- 1 x 3.5mm audio cable
- 1 x User Manual
- 1 x warranty card

Connect power

With a built-in battery, this device allows you to enjoy music or charge your portable devices on the go. Before use outdoors, make sure that the built-in battery is fully recharged.



Connect the supplied power adapter

Tip: To recharge the built-in battery, you need to turn on the device.

Turn on the device

Press  on the top panel.

- ☞ The  indicator flashes white and red alternately, and turns red when the built-in battery is fully recharged.
- ☞ The  indicator flashes white and the device enters Bluetooth pairing mode automatically.

Turn off the device:

Press and hold  on the top panel.

- ☞ Both the  and  indicators turn off.

Pair with a Bluetooth-enabled device

Before using the Bluetooth feature of OontZ XL for the first time, you need to pair OontZ XL with another Bluetooth- enabled device, such as an iPod/ iPhone/iPad, Android smartphone, PC, or Mac. After successful pairing, each time when the paired device (Bluetooth-enabled) and OontZ XL are powered on and within the detectable range (32 feet or 10m), they will be wirelessly connected to each other automatically.

Notes:

- If your paired device fails to connect with OontZ XL after activation, you may need to select the device name of OontZ XL from the list of Bluetooth equipment on your paired device to set up wireless connection again.
- Make sure that OontZ XL and the device to be paired are located within the detectable range (32 feet or 10m).

1. Enable the Bluetooth function on your device to be paired with OontZ XL.

- ☞ The device to be paired with OontZ XL enters Bluetooth searching mode.
- ☞ After a while, “OontZ XL” is displayed in the list of Bluetooth equipment on the device to be paired with OontZ XL.

2. Select “OontZ XL” on the device to be paired with OontZ XL to start pairing (if required, enter the password “0000”).

- ☞ After successful pairing, the indicator on the top of OontZ XL turns white steadily and the speaker beeps.

Tip:

- You can press and hold the button on the top of OontZ XL to remove the existing pairing information. In this case, the indicator starts to flash white again and the speaker returns to Bluetooth pairing mode.

Play music from a Bluetooth connected device

Note:

- Make sure that wireless connection has been set up between the paired device and OontZ XL.

Start music play on your device paired and connected with OontZ XL.

- ☞ You can hear music streamed to the Bluetooth wireless speaker.

During music play, you can:

Press  /  on the top panel to skip to the previous/next song.

Press  on the top panel to pause or resume music play.

Press  /  on the top panel to adjust volume.

Press  on the top panel to mute or resume sound output.

Use OontZ XL as a speaker phone

If the paired mobile phone is compatible with Bluetooth profiles HFP, you can use OontZ XL as a speaker phone to answer/reject a call, or hang up. This is very useful when you want to have a teleconference.

Notes:

- Make sure that your mobile phone is compatible with Bluetooth profiles HFP. See the user manual of your mobile phone for details.
- Make sure that wireless connection has been set up between the paired mobile phone and OontZ XL.
- When there is an incoming call, music play will be paused.

When there is an incoming call, you can:

- Press  on the speaker phone to answer the call.
- Press and hold  on the speaker phone to reject the call.


During a call (incoming or outgoing), you can:

- Listen through the speaker phone.
- Speak towards the microphone located at the left side of the speaker phone.
- Press **VOL +/-** on the speaker phone to adjust volume.
- Press on the speaker phone to hang up.

Listen from an auxiliary device

Through this speaker system, you also can listen to music from any auxiliary device with a 3.5mm headphone socket, such as a PC or an MP3 player.

1. Connect the supplied 3.5mm audio cable.
 - One end to the AUX IN socket on the back panel
 - The other end to the 3.5mm headphone socket on an auxiliary device




2. Start music play on the auxiliary device.

During music play, you can:

- Press  /  on the top panel to adjust volume.
- Press  on the top panel to mute or resume sound output.

Charge a portable device through the USB socket

You can charge your portable devices, such as your mobile phone or MP3 player through the USB socket on the back panel.



Connect a USB charging cable (not supplied):

- One end to the USB socket on your portable device
- The other end to the USB socket on the speaker

Specifications

The technical specifications are subject to change without prior notice.

AC power	Input: 100-240V~50-60Hz 0.8A Output: 15V 1500mA
Output power	2 x 7W
Frequency response	50Hz-20KHz
Speaker drivers	2.25" *2 full range + (2" *3.5") *3mm passive radiators
S/N	≥75dB
THD+N	≤1% (1kHz, rated power output)
Battery Life	15H at 75% Volume
Dimension	(W x H x D) 260 x 90 x 80 (mm)
Weight	1.034kg (net); 1.6kg (gross)
Audio input	1 x 3.5mm socket; 1 x wireless input (Bluetooth)
Wireless	Bluetooth 2.1 (A2DP)

Trouble Shooting

Problem	What Should I do?
No power	Press Power button to turn on the speaker
	Ensure the Speaker is fully charged or you have the speaker to power source
No sound or only distorted sound	Check the Bluetooth connected device supports A2DP
	Press Vol-/+ button to adjust volume
	Check whether the sound output is muted. Press Power button to resume sound out
	Check whether wireless connection has been set up between the paired device and Speaker
Cannot answer calls	Check whether wireless connection has been set up between the paired device and Speaker
	Check whether the paired mobile phone supports Bluetooth profile HFP
I cannot control the music from my Speaker	Ensue your Bluetooth device supports AVRCP
	Press Bluetooth button to resume music
Music does not resume after hanging up a call	Ensure you have paired the speaker correctly with your Bluetooth device (Paring the OontZ XL with a Bluetooth Device (First time connection))
	Resume music play on the Bluetooth connected device
I cannot find OontZ XL on the Bluetooth device	Make sure you have enabled the Bluetooth function on the device paired with OontZ XL
	Check whether OontZ XL is connected wirelessly with another paired device. OontZ XL only supports one Bluetooth connection at a time
I cannot charge my mobile devices through the USB socket	Check whether you have connected a USB cable to both OontZ XL and your mobile device securely
	Built-in battery of OontZ XL may be drained Connect the speaker to AC mains