




# Portable Bluetooth Radio



## Include

- Portable Bluetooth Radio • 1 unit
- Micro USB Charging Cable • 1 pc
- AUX Cable • 1 pc

## FM Mode

- Rotate volume knob clockwise to turn on the device
- Turn mode switch knob to get the triangle on the knob pointing to "FM"
- White LED indicator above "FM" will be on
- Rotate FM/AM tuning knob to find your favourite FM radio stations.

## AM Mode

- Rotate volume knob clockwise to turn on the device
- Turn mode switch knob to get the triangle on the knob pointing to "AM"
- White LED indicator above "AM" will be on
- Rotate FM/AM tuning knob to find your favourite AM radio stations.

## AUX Mode

- Rotate volume knob clockwise to turn on the device
- Turn mode switch knob to get the triangle on the knob pointing to "AUX"
- White LED indicator above "AUX" will be on
- Plug one end of the AUX cable (provided) into 3.5mm headphone jack or AUX OUT jack on your external audio device, the other end to the AUX IN jack on the back of the unit
- Play your favourite music on your external audio device.

## Bluetooth Mode (Receiver mode=RX)

- Rotate volume knob clockwise to turn on the device
- Turn mode switch knob to get the triangle on the knob pointing to "BT", and toggle Bluetooth RX/TX switch to "RX"
- White LED indicator above "BT" will be breathing; the device is ready to pair
- Please use your phone to search and connect "Hearth & Hand 01"
- Solid white light on once connected successfully.

## Bluetooth Mode (Transmitter Mode=TX)

- Rotate volume knob clockwise to turn on the device
- Turn mode switch knob to get the triangle on the knob pointing to "BT"
- Toggle Bluetooth transmitter switch to "TX"; then the fast flashing orange light on and device is ready to pair
- Turn your Bluetooth receiver (such as BT headset) on, and put it within the connection range; devices will be paired automatically
- Breathing orange light on once connected successfully
- Turn the mode switch knob to AM, FM or AUX to enjoy the sounds (through Bluetooth receiver) from radio stations or the external audio input device connected with the AUX cable.

front

4 in

## Charging

- Plug micro USB end of charging cable into charging port
- Plug USB end of charging cable into a DC 5V 1A power adaptor
- Full charge requires approximately 3-4 hours
- Red light is always on when charging, and will turn off when the device is fully charged.

## Troubleshooting and Tips

- If the device is not working correctly, turn it on/off to reset
- If the device won't turn on, recharge the battery and try again
- If the device won't charge, make sure the supply works, is 5V --- 1A, and not damaged
- If the device makes no sound, adjust the volume
- If the device makes no sound or do not show as an available device, make sure it is not paired to another device. If so, unpair the device and re-pair the desired device
- This device does not have a pairing tone. If prompted for one, make sure you are connecting to the correct device. If not, "forget" the device and re-pair with your desired one.

## NOTE:

- Please keep the distance between the connected devices less than 33 feet to ensure working properly

## SPECIFICATIONS:

- Power Input: 5V ---1A
- Built-In Battery: 1800 mAh
- Bluetooth Pairing Name: Hearth & Hand 01

## Need some help?

Can't get it to pair? Not accepting phone calls? Just have a question?



Call us at: 877-698-4883



Online at: [TargetTechSupport.com](http://TargetTechSupport.com)

## Safety

- Do not use near any water source
- Do not modify or repair this device
- Do not use in high temperatures or extreme weather
- Do not use chemical detergents to clean your device, use a soft dry cloth



FCC ID: OKUJC8105 Model: Grizedale Input: 5V --- Max 1A Made in China  
 This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
 (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
 NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- Target Corp.Mpls.MN,55403 Phone:1-612-304-6073

back

5.6 in