


## RMC1300 User Guide



### I. Product Introduction

RMC1300 is a 433MHz wireless remote control. Push the button, and it will send arm/disarm/panic signal to the system.




#### System Structure



## II. Installation

- (1) Usage scenario:
  - Indoors and away from direct sunlight.
  - Away from extreme temperature sources and large metal objects.
- (2) Operation:
  - Unscrew the screw to open the back cover of Remote control.
  - Insert the battery noting the polarity (A23 battery); Slide back the cover and screw fastening with the front cove.

## III. User Instruction& Workflow

- (1) Press “” once to set arm mode of the system.
- (2) Press “” once to set disarm mode of the system.
- (3) Press “” once to send an emergency alert to the system.
- (4) If RMC1300 is in low battery status( $9.6 \pm 0.4V$ ), it will report a message to the system along with the control signal generated when one of the buttons is pressed. Please change the battery then.

## FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.