

APPENDIX 3: Photographs of test setup

Radiated Emission Antenna(DR/AS)




Photo 1



Photo 2

UL Japan, Inc.

Ise EMC Lab.

4383-326 Asama-cho, Ise-shi, Mie-ken 516-0021 JAPAN

Telephone : +81 596 24 8999

Facsimile : +81 596 24 8124

Radiated Emission
Antenna(TG/INF/INR)




Photo 1



Photo 2

Radiated Emission
Push Start Switch




Photo 1





Photo 2

Worst Case Position

Antenna (DR/AS)

Below 30MHz: X

**Above 30MHz: Horizontal X, Vertical X
X-axis**



Y-axis



Z-axis




Antenna (TG/INF/INR)

Below 30MHz: X


**Above 30MHz: Horizontal X, Vertical X
X-axis**



Y-axis



Z-axis



Worst Case Position

Push Start Switch

Below 30MHz: X
Above 30MHz: Horizontal X, Vertical X
X-axis



Y-axis




Z-axis



ECU

Below 30MHz: X
Above 30MHz: Horizontal X, Vertical X
X-axis



Y-axis



Z-axis



End of Report

UL Japan, Inc.

Ise EMC Lab.

4383-326 Asama-cho, Ise-shi, Mie-ken 516-0021 JAPAN

Telephone : +81 596 24 8999

Facsimile : +81 596 24 8124