




# Flood Light with Remote Control


SKU NO. 1006215593



Do not plug in the flood light onto an outlet until it is fully assembled and the flood light is properly connected

Please read the enclosed important safety instructions and warnings carefully prior to use and save these instructions for reference.

## PACKAGE CONTENTS



Flood light x1



Remote Control x1

## PRODUCT SPECIFICATION

Input: 120V~ 60Hz, 0.3A, 36W

Lights: RGB LED

Operation: Indoor/outdoor

Operating Temperature: -15°F to 90°F (-26°C to 32°C)

Dimension: 5.7 in x 3.54 in x 1.18 in

Maximum Projection Distance: 6ft

Warranty: 3 Years Limited

## INSTALLATION

1. Adjust the lighting direction up and down as your need.
2. According to the spacing of two screw bits on the bracket, drill two holes on the mounting panel and fix it with two bolts.
3. Presetting timer: 6hrs on, 18hrs off.
4. Use the remote to switch flood light function.




Fig.1





Fig.2

## REMOTE CONTROL

Function of Remote Control



- Note:**
1. Please insert 2 pieces of AAA Battery before use. (Battery not included)
  2. If the remote control does not work, check whether the battery of the remote control is out of power.

**WARNING:** This is not a toy and is not intended for use by children.

- (A). Do not dispose of the battery in fire as the battery may leak and explode.
- (B). Do not mix old and new batteries and not mix alkaline, standard(carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- (C). Exhausted batteries are to be removed from the product.
- (D). Dispose of battery properly by following directions on battery.
- (E). Use AAA batteries only. Use of other batteries may damage remote control.
- (F). Safe for indoor use.
- (G). Do Not keep the remote control near heat or moisture. Keep the remote control in a proper place while not using.

## SAFETY INFORMATION

## CAUTION

1. To reduce risk of danger:
  - 1) Do not break the Flood light in anyway as this may damage wire insulation.
  - 2) Do not attempt to open the housing of Flood light or modifying the flood light as it will void all warranties.
2. Do not use in a bathroom.
3. Do not operate unit with damage plug.
4. Do not operate unit if it has been subjected to damage in anyway

## WARNING

1. Always ensure light set is unplugged when installed
2. This is an electric product-not a toy! To avoid risk of fire, burns, personal injury and electric shock, it should not be played with or places where children can reach it.
3. Do not use this product for other than its intended use.
4. Please check if the light and parts are intact before installation.
5. Please do not place this light in corrosive conditions.
6. If there is a damage to the cord, please cut off the power the and stop using it immediately.
7. Please do not retrofit the light within the warranty period.
8. To ensure the light works properly, please use the voltage indicated on the packing.
9. To avoid any damage to the light, please do use chemical solvent during routine maintenance.

## FEDERAL COMMUNICATIONS COMMISSION (FCC) STATEMENT

### FCC CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.