

### Introduction

Congratulations on your purchase of the Targus Miralogic Smart Power Strip.

### Contents

- (A) Miralogic Smart Power Strip
- (B) User Guide

### Features

- Stylish design for enterprise and office use.
- Capture power consumption data on each individual device plugged into the outlets.
- Deliver power consumption analytics to the Miralogic Software Platform via the Universal Smart Dock.
- Each outlet can be remotely managed (e.g. turned on / off) via the Miralogic Software Platform.

### Technical Specification

Number of AC outlets: 4  
 Maximum Current or Power: 120V, 8A or 960 watts  
 Input: 120VAC 60Hz 8A Max  
 Output: 120VAC 60Hz 8A Total (5A max per outlet)

### Intended Use

This product is intended for enterprise use only. It is not intended for household use.  
 This product is intended to be used in dry indoor area only.  
 No liability will be accepted for damaged resulting from improper use or non-compliance with these instructions.


### Before First Use

Check for any transport damages.  
 Before connecting the product to the power source, check that the power supply voltage corresponds with the input line voltage details shown on the rating label.

### Using the Product

Connecting to a power source  
 Place the product nearby the power source and connect the power plug.

- Power switch indicator (Red):** The product is powered on.
- Not Grounded (Red):** The power is not grounded.
- Power indicator (Green):** The product is powered on.
- Connected indicator (Blue):** The product is successfully connected to the Miralogic Software Platform via the Universal Smart Dock.



### Circuit breaker

DO NOT OVERLOAD the product's outlets. The product can accommodate a total AC loading up to 8A (960W) (spread out over multiple outlets but single outlet can only withstand a maximum of 5A). If the AC loading exceeds 960W, the built-in circuit breaker (inside the power rocker switch) will trip and the outlets will stop providing power immediately (red indicator goes off).

In case the circuit breaker trips, proceed as below:

1. Unplug all the connected equipment.
2. Press the power rocker switch and make sure the red indicator is on.
3. Connect all the equipment one by one. While doing so, do not exceed a total AC loading of 960W.

### Cleaning and Maintenance

To prevent electric shock, unplug before cleaning  
 During cleaning, the electrical parts of the product shall not be immersed into water or other liquids. Never hold it under running water.

#### Cleaning

- Unplug the product from the wall AC outlet, wipe with a soft, slightly moist cloth.
- Dry the product after cleaning.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.

#### Maintenance

- Store in a cool and dry place away from children and pets.
- Avoid any vibrations and mechanical shocks.

### CAUTION

- USE INDOORS AND IN DRY LOCATIONS ONLY TO REDUCE THE RISK OF ELECTRIC SHOCK.
- TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT PLUG INTO ANOTHER RELOCATABLE POWER TAP.
- INSPECT THOROUGHLY BEFORE EACH USE. DO NOT USE IF DAMAGED IN ANY WAY.
- ONLY INTENDED FOR USE WITH SMALL ELECTRICAL APPLIANCES SUCH AS NOTEBOOK COMPUTERS, MOBILE PHONES AND OTHER LOW VOLTAGE DEVICES.
- ENSURE THAT THE TOTAL CURRENT/POWER REQUIREMENT OF THE ATTACHED APPLIANCES DOES NOT EXCEED 120V, 8A OR 960 WATTS.
- SMART POWER STRIP MAY BE PERMANENTLY DAMAGED IF IT IS CONNECTED TO A POWER SOURCE GREATER THAN 120V AC.

## Technical Support

For technical questions, please visit: <http://www.targus.com/support.asp>

## Warranty

Targus warrants this product to be free from defects in materials and workmanship for three years. If your Targus accessory is found to be defective within that time, we will promptly repair or replace it. This warranty does not cover accidental damage, wear and tear, or consequential or incidental loss. Under no conditions is Targus liable for loss of, or damage to a computer; nor loss of, or damage to, programs, records, or data; nor any consequential or incidental damages, even if Targus has been informed of their possibility. This warranty does not affect your statutory rights.

## FCC statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**RF exposure statements: Section 2.1091(d) (3) - Mobile devices (a minimum separation distance may be required).**

*e.g. This device must be used in fixed locations and in such a way that a separation distance of at least 20 centimeters is normally maintained between the transmitter's radiating structure(s) and the body of the user or nearby persons.*

## IC statement

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

