


INSTRUCTION MANUAL

WARNINGS

This appliance is intended for domestic household use only and should not be used for any other purpose or in any other application, such as for non domestic use or in a commercial environment.







Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type. batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

OVERVIEW



- ⏻ Power on or Power off.
- 🔗 short press for entering pairing mode. long press to cancel the pairing mode.
- + Increase volume or select next track
- Decrease volume or select last track

BLUETOOTH OPERATION





1. Press  for 2 seconds to turn on the speaker. The indicator light will flash to detect Bluetooth enabled devices near you. The indicator light will go off if no Bluetooth device is detected within 5 minutes.
2. Press  on to back of the speaker to play/pause. Push  shortly to select next track, push and hold  to increase the volume. Push  shortly to select last track, push and hold  to decrease the volume.
3. When you want to play music or movie from another Bluetooth device, disconnect the speaker and restart the Bluetooth speaker and re-pair.

CHARGING THE SPEAKER

The speaker has a built-in Lithium battery. The battery is rechargeable and provides approx 3.5 hours continuous operation when fully charged.

Use the micro-USB cable to charge the speaker. The red indicator light will illuminate. The red indicator light will go off when the speaker is fully charged.

SPEAKER PHONE OPERATION

- Press  to answer an incoming call.
- Press  to hang up.
- Keep pressing  to reject an incoming call.
- Double press  to redial the last phone number.

SPECIFICATION

FCC ID: OYCTWSBT142

Product Model : TWS BT142

Bluetooth Specifications : Bluetooth V4.2

Transmission Distance : ≤10M (depending upon operation environment and devices to which it connects)

USB Recharge Voltage: DC 5V

Built-in Battery: Lithium battery 500mAh*2

Output Power of single speaker: 5W/5W

Frequency Response: 90Hz-20KHz

Sensitivity: 80db±2db

Signal to Noise Ratio (SNR):≥80dB

Accessories

Speaker *2

Micro USB charging cable * 2

User Manual *1

Touble shooting

Faults / Phenomena	Solutions
Unable to pair up with other devices	<ol style="list-style-type: none">1. Check whether the speakers are still in the process of search or switch it off and then on.2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Please turn them off.
The sound is rather low or distorted	<ol style="list-style-type: none">1. Check the Bluetooth device's volume and then adjust it to a proper level.2. Recharge the battery
The music stops from time to time	<ol style="list-style-type: none">1. Check whether the speaker's effective transmission range is exceeded or there is an obstacle standing between the speaker and other Bluetooth devices.
The Bluetooth indicator remains off	<ol style="list-style-type: none">1. It suggests the battery power drops quite low and retry once being recharged.2. Turn it on again.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.