


2. Photograph for the test configuration



3. Sample Calculation

The emission level measured in decibels above one microvolt (dB) was converted into microvolt per meter (/m) as shown in following sample calculation.

For example :

	Measured Value at	<u>0.125 MHz</u>	86.0 dB
+	Antenna Factor		9.9 dB
+	Cable Loss		0.0 dB
	Preamplifier		0.0 dB
	Distance Correction Factor *		80.0 dB
=	Radiated Emission		15.9 dB /m
			(= 6.2 /m)

* Extrapolated from the measured distance(3 m) to the specified distance(300 m) using the square of an inverse linear distance extrapolation.